



# PTT Dispatch Console

## User Guide (v. 2.12)

*Version 2.12*



**Bell**

<b>1. INTRODUCTION AND KEY FEATURES.....</b>	<b>5</b>
1.1 Key Features:.....	5
<b>2. GETTING STARTED .....</b>	<b>6</b>
2.1 Prerequisites .....	6
2.2 How to Install the Dispatch Console .....	7
2.3 Launching the PTT Dispatch Console .....	8
2.4 Logout from PTT Dispatch Console .....	8
2.5 Exit PTT Dispatch Console .....	8
<b>3. GETTING TO KNOW THE PTT DISPATCH CONSOLE.....</b>	<b>9</b>
3.1 Navigation Areas .....	9
3.2 Docking/Undocking .....	10
3.3 Reset Layout .....	10
3.4 Searching .....	10
<b>4. CONTACTS AND GROUPS .....</b>	<b>11</b>
4.1 How to Add Contacts .....	11
4.2 How to Navigate the Contacts Tab .....	11
4.3 Groups Tab .....	12
4.4 My Local Groups Tab.....	12
<b>5. PTT CALLS .....</b>	<b>13</b>
5.1 Call Activity Window .....	13
5.2 Making a PTT Call.....	13
5.2.1 Group Call.....	13
5.2.2 Quick Group Call .....	15
5.2.3 One-to-one.....	15
5.2.4 Broadcast Call .....	15
5.2.5 Call from the Alerts window .....	17
5.2.6 Call from the Map .....	17
5.2.7 Call from Call Logs .....	18
5.3 Receiving Calls .....	18
5.4 PTT Call Behavior While the Dispatch Console is in the Background.....	18
5.5 Rejoining a Group Call .....	19
<b>6. USING THE MAP .....</b>	<b>20</b>
6.1 Locating.....	20
6.2 Clear located fleet members on the map .....	20
6.3 Fleet Member Information Window .....	21
6.4 To select multiple fleet members: .....	21
6.5 Finding an address.....	21
6.6 Auto tracking a fleet member .....	21

<b>7. RECORDING CALLS .....</b>	<b>22</b>
7.1 Full Session Recording .....	22
7.2 Manual Recording .....	22
7.3 Playing Back Recorded Calls.....	23
<b>8. ALERTS .....</b>	<b>24</b>
8.1 Instant Personal Alerts (IPA).....	24
8.1.1 Sending an Alert .....	24
8.1.2 Receiving an Alert.....	24
<b>9. MONITORING GROUPS .....</b>	<b>25</b>
9.1 Adding a Group to Monitored List .....	26
9.2 Removing a Group from Monitored List .....	27
9.3 Actions on Monitored Group .....	27
<b>10. TALKGROUP SCANNING .....</b>	<b>28</b>
10.1 Adding Monitored Groups to Talkgroup Scan List .....	28
10.2 Enabling Talkgroup Scanning .....	29
10.3 Turning Talkgroup Scanning Off .....	29
<b>11. USING THE MAP.....</b>	<b>30</b>
11.1 Locating single/multiple fleet member(s) .....	30
11.2 Fleet Member Information Window .....	31
11.3 Clear all located fleet members on the map .....	31
11.4 Managing fleet members.....	32
<b>12 REAL-TIME PRESENCE.....</b>	<b>33</b>
12.1 PTT Contact/Fleet Member's Presence .....	33
12.2 Your Presence .....	33
<b>13 USING ACCESSORIES.....</b>	<b>34</b>
13.1 Notification Message on Connection .....	34
13.2 Using Headset.....	34
13.3 Using Footswitch.....	35
<b>14 SETTINGS.....</b>	<b>36</b>
14.1 Generic Settings.....	36
14.1.1 Alert Settings.....	36
14.1.2 Backup/Archive Settings .....	36
14.1.3 Date/Time Format Settings .....	37
14.1.4 Recording Settings.....	37
14.1.5 Application Settings.....	37
14.1.6 GPS Expiry Settings.....	37
14.1.7 Report Settings .....	38

14.1.8 Device Settings .....	39
14.1.9 Tones .....	39
14.1.10 About .....	39
14.2 Map Settings .....	40
14.2.1 Map Color Settings .....	40
14.2.2 On-Demand Location Settings .....	42

# 1. Introduction and Key Features

The PTT Dispatch Console is a feature rich windows-based application that enables organizations to effectively manage daily dispatch operations.

It provides PTT calling, location, alerts, and indicates presence through an intuitive user interface. Dispatch Console allows a dispatcher to operate from a centralized corporate facility and manage the activities for a set of mobile PTT users (also called fleet members) working in the field. This enables an organization to effectively manage day to day dispatch operations and rapidly respond to incidents, urgent situations, customer requests, facility events, and other situations that require quick actions.

## 1.1 Key Features:

**Contacts and Groups** – You can establish a one-to-one call or send/receive Instant Personal Alert (IPA) to a contact. A dispatch group allows one-to-many calls from you to fleet members. Contacts and Groups are managed and pushed to the Dispatch Console by the Corporate Administrator Tool (CAT) administrator (CA).

**PTT Calling**– Enables you to start or end a Push-to-talk (PTT) call, record a conversation, and see the talker identity. The PTT Dispatch Console shows call activities during the call.

**Monitored Groups**– Allows you to monitor call activity on up to 16 Talkgroups, turn Talkgroup Scanning on, join an existing active group call or initiate a new group call.

**Alerts**– Allows you to view Instant Personal Alerts (also known as IPA or call-me alerts) and missed call alerts sent to the dispatcher by the fleet members and take action.

**Map**– Provides visual location information of the fleet members periodically or on-demand . Dispatchers can also make PTT calls or send alerts to those fleet members directly from the map.

**Presence**– View fleet member availability (i.e. “Available”, “Do Not Disturb”, and “Offline”)

**Logs**– Provides information about recent activity on the Dispatch Console including alerts, PTT calls, and audio recordings of recorded calls.

**Panel Undocking**– Allows you to separate a section of the Dispatch Console for larger viewing or for display on a different monitor.

**Map Setting** - Configure Map Color Settings and On-Demand Location Settings

# 2. Getting Started

## 2.1 Prerequisites

The PTT Dispatch Console requires the following minimum system configuration:

1. Hardware Requirements:

- Processor: Dual Core 2.1 GHz (minimum) Intel Core i5 or above
- RAM (Memory): 4 GB (minimum)
- Minimum required Hard Disk space: 1GB required for the installation (5GB or higher is recommended depending on your storage needs)
- Monitor: 20.1 inches or better flat panel LCD Monitor with a 1600 X 1200 resolution setting (recommended).
- A standard sound card supporting a headset and speaker
- 2+ Mbps Data Connectivity

---

**Note: The disk space specified includes the space required for recording the call conversation, storage of reports, and also for storage of backup files.**

---

2. Operating System Requirements:

- Windows 7 Professional Edition SP1 32-bit or 64-bit version  
OR
- Windows 8.0/8.1, Windows 8.0/8.1 Pro or Enterprise 32 bit or 64 bit version  
OR
- Windows 10 Pro or Enterprise 32 bit or 64 bit version

3. Software Requirements:

- Internet Explorer (IE) 11 or Microsoft Edge 25 with File Download and Script options enabled.
- (DOT) .Net Framework 3.5 and above
- Windows Media Player 10 and above

#### 4. Network Requirements

- You must disable firewall services on your laptop/desktop before installing the Dispatch Console.
- Ports 443, 80 and 8080 must be open to both install and run Dispatch Console.
- Dispatch Console does not support authenticated HTTP/SOCKS proxies to establish a connection with the PTT server. The communication path between Dispatch Console and the PTT server uses a TLS connection.

#### 5. Mobile Device Requirements

- Android and iOS smartphones with the latest version of PTT installed

---

**Note: You will need administrative privileges to install Dispatch Console.**

**It's recommended that PTT Dispatch Console is used over a dedicated PC.**

---

## 2.2 How to Install the Dispatch Console

Step 1- Log in to the Corporate Administrator Tool (CAT), select the dispatcher profile and enter in the dispatcher's email address. Click "Generate Activation Code", a window will ask the user to send the download link and activation key. Click on "Send Mail" to confirm.

Step 2- Click the link provided in the activation e-mail to download the PTT Dispatch Console pre-installer. This activation email also contains the activation key information for initializing the PTT Dispatch Console.

Step 3- Double-click the PTT Dispatch Console pre-installer in the downloads folder once the download is complete.

Step 4- Select the language for Installation Instructions and Dispatch Console and continue following the on screen prompts.

---

**Note: All the PTT Dispatch Console operations, such as installation, uninstallation, upgrade and restore need administrative privileges.**

**For Windows 7 Operating System, a dialog box appears as User Account Control according to the control settings, during the installation procedure. To continue with the installation process, click Yes.**

---

---

Please disable the VPN on your laptop/desktop before downloading the pre-installer, installing and launching the Dispatch Console

---

## 2.3 Launching the PTT Dispatch Console

Access the PTT Dispatch Console from the Windows Start Menu. You can find the application under Windows Start menu > All programs menu > PTT Dispatch Console menu > PTT Dispatch Console.

**OR**

Double click the desktop shortcut icon on desktop.

---

**Note:** The first time you launch, you will be prompted to enter an activation key. The activation key is provided by your corporate administrator, usually through an automated email message. If you do not have a valid activation key, please check with your administrator.

---

## 2.4 Logout from PTT Dispatch Console

To dismiss the PTT Dispatch Console window, click the **Logout** button on the top right-hand corner of the PTT Dispatch Console's home page. The **Logout** button will close the application window and log you out from the application.

## 2.5 Exit PTT Dispatch Console

To completely stop the PTT Dispatch Console, go to the Windows system tray at the bottom of the screen and find the Dispatch Console icon (typically on the right-hand side of the Windows task bar). Right click on the PTT Dispatch Console icon and click on "Exit".




# 3. Getting to know the PTT Dispatch Console

## 3.1 Navigation Areas

The Dispatch Console consists of the following major navigation areas (also called Windows):

- Contacts and Groups
- Call Activity
- Alerts
- Monitored Groups Activity
- Map Logs
- Call logs and Alert logs
- Settings: Global settings and Map settings

The figure below points to each of these major areas:



## 3.2 Docking/Undocking

Windows can be docked or undocked. When a window is docked, it is part of a larger window. An undocked window can be moved around the screen or even dragged onto another display monitor.

To undock a window, drag and drop or double click the title bar of the window to be undocked.

To dock a window back to its position, double click the title bar of the window.

## 3.3 Reset Layout

To reset the layout click the **Reset Layout** button located on the right side of the Dispatch Console (as shown in the image above).

## 3.4 Searching

Contacts and Groups can be searched using the search bar on the **Contacts and Groups** window. To search, select a tab (Contacts, Groups, or My Local Groups) and enter the fleet member's name or group's name in the **Search** field. The list will be filtered to show matching entries.

---

**Note:** You can also search logs for calls and alerts from the logs tab situated besides the Map tab.

---

## 4. Contacts and Groups

The contacts and groups are added and pushed to the PTT Dispatch Console using the Corporate Administrator Tool (CAT). Once configured by the corporate administrator, the contacts and groups are shown on the **Contacts and Groups Window**.

### 4.1 How to Add Contacts

#### Adding fleet members for the first time:

1. In the Corporate Administrator Tool (CAT) click on **Add New Group** from the **Manage Groups Tab**
2. Select **Dispatch Group** under **Select Group Type**
3. Select the Dispatcher the contacts will be added to
4. Give the Dispatch Group a name under the Group Identity
5. Under the **Manage Members Tab**, Click **Add Individual Members** to add members
6. At the bottom of the Corporate Administrator Tool click **Add** to confirm all actions.
7. A **Dispatch Confirmation Question** will appear. Check the box to push contacts to the Dispatcher.


---

**Note:** To locate a fleet member, the fleet member must be listed and assigned to the Dispatcher's groups and contact list through the Corporate Admin Tool (CAT). In addition, the GPS feature must be enabled on the fleet member's phone.


---

### 4.2 How to Navigate the Contacts Tab


Within the Contacts Tab, you can select a contact for calling, send a call-me alert, or locate a fleet member. To do this, follow these steps:

1. Select the **Contacts** Tab
2. Select the checkbox for individual fleet member to make an one to one call, send an Instant Personal Alert (IPA) or to locate.
3. Click:
  - Call  icon to place a call

OR

- IPA  icon to send an Instant Personal Alerts (IPA)

OR

- Locate  icon to locate the fleet member on the map

---

**Note:** Instant Personal Alerts (IPA) to a quick group is not allowed.

---

You can select multiple individual fleet members to perform a Quick Group call or locate at once

You can sort by name, GPS status, or presence status by clicking on the column label. By default the contacts will be sorted by name.

## 4.3 Groups Tab

You can call or locate a group from the Groups Tab.

1. Select the **Groups** Tab, to display Groups Tab Window.

---

**Note:** Sending an Instant Personal Alert (IPA) to a group is not allowed.

---

## 4.4 My Local Groups Tab

With local groups, you can manage and communicate with your own personal groups. These personal groups are stored locally within the PTT Dispatch Console.

---

**Note:** Local groups are not managed by the corporate administrator.

---

Creating Local Groups:

To create a local group, follow these steps:


1. Select the fleet members from the **Contacts Tab** and right-click to create **Local Group**. A *My Local Group* Window appear.
2. Enter the name of the local group in the **Name** field.
3. Click **Save** to save the new local group

OR

**Cancel** to abort.

# 5. PTT Calls


## 5.1 Call Activity Window


When you select a contact or group from any window like Contacts and Groups, MAP info, MAP Selection List, Alerts, Call and Alert Logs and click on the call  button, the Call Activity Window will change to "Call Ready" state. When a call ends the 'Call Activity' window will switch back to 'Call Ready' state for the last dialed or received call.

## 5.2 Making a PTT Call


### 5.2.1 Group Call

To place a PTT group call:





1. Click on **Groups** Tab and select the **Group Name** from the *Contacts and Groups Window*. To select the group, click the checkbox next to the group name.
2. Click  icon to place a group call, you can see *Call Ready* screen at the Call activity window, as shown below.



- Use **Call Activity Window** to initiate a group call by clicking and holding the PTT button. A Call type status appears on the header area of the *Call Activity Window*.



The following information is displayed:


- **Call Type** is displayed in the header area
  - **Push-to-talk** button allows you to take the floor. The color of the button indicates whether the floor is free (gray), you are talking (green), or someone else is talking (red)
  - **Talker** field show the name of the person speaking
  - **Name** field shows the name of the group
  - **Members** allows you to see the names of the group members in a drop-down list
  - **Record**  button can be used to record the call
  - **End Call**  allows you to drop from the current call
- To talk, click and hold the on-screen PTT button. The PTT button will turn green  . When finished talking, release the on-screen PTT button again to allow other fleet members to speak.
  - When a fleet member takes the floor, the on screen PTT button will turn blue  and the name of the talker is displayed in the **Talker** field.

6. Click **End Call** to drop yourself from the call. The call will continue without you. The call will automatically end if no one takes the floor.

### 5.2.2 Quick Group Call


A Quick Group call is an ad hoc call consisting of selected fleet members. Quick Group calls are generally special purpose groups that are used once. If you use a group often, you should have the corporate administrator create the group for you, or create a My Local Group.

To place Quick Group call:

1. Click on **Contacts Tab** and select the desired fleet members from the **Contacts and Groups Window** using the checkbox next to the fleet members' names.
2. Click  icon to place a Quick Group call, you can see *Call Ready* screen at the Call activity window.
3. in Call Activity Window. The group name for a Quick Group call is shown as "None". Members list shows members of the Quick Group.

### 5.2.3 One-to-one

To place a PTT call to an individual fleet member, follow these steps:

1. Click the **Contacts Tab** and find the fleet member from the **Contacts tab of the Contacts and Groups Window**.
2. Select the checkbox next to the name of the fleet member.
3. Click  icon to place a one-to-one call, you can see *Call Ready* screen at the Call activity window, as shown below.
4. A call starts and the same information is shown in the Call Activity Window as for a group call.

---

[Note: The tones can be enable/disable to set the call tones refer to section \*Tones\*](#)


---

### 5.2.4 Broadcast Call


Broadcast calling provides the ability for a dispatcher to make a one-way, high priority call to up to 499 subscribers. Since it's a one-way group call, participants cannot talk back. Broadcast calls pre-empt any active ongoing calls that a PTT subscriber is on.


Broadcast groups are created and administered by the CA through the CAT. Refer to the CAT User Guide 8.0 for more details on Broadcast group creation and management.

Once a CA has assigned a Dispatcher to a Broadcast group, the Dispatcher should be able to see this group in the “Broadcast Groups” tab under the “Contacts and Groups” window in the Dispatch Console:




#### To place a Broadcast Call:


1. Select the checkbox next to the Broadcast Group name
2. Select the PTT call button 
3. Select “Yes” when prompted:



4. Push the PTT call button to initiate the Broadcast Call:







5. Select the End Call  button when the Broadcast Call is complete.

### 5.2.5 Call from the Alerts window


To place a call from the *Alerts Window*:


1. Select and right-click on the alert on Alerts Window.
2. Click  icon to place a call. The call is returned to the Alert's originator.




### 5.2.6 Call from the Map

To place call from the *Info Window* on the map:

1. Click on the marker icon for the fleet member on the map to display the Info Window
2. Click  icon to place a call.




To place a call from the *Selection List Window* on map:

1. Select the checkbox for the individual fleet members in the ***Selection List Window***.
2. Click  icon to place a call.



### 5.2.7 Call from Call Logs

To place a call from the *Call Logs Window*:

1. Select Logs and then select Call Logs
2. Select and right-click on a conversation row from the Call Logs History.
3. Click  icon to place a call
  - a. For *One-To-One call* the call is returned to the originating fleet member.
  - b. For *Group call* the call is returned to the members of the group.
  - c. For *Quick Group call*, the call is returned to all the fleet members of the Quick Group call.

## 5.3 Receiving Calls

You can receive an incoming call from the fleet members, any fleet member can directly contact you using One-to-One call. The call is only received by the PTT Dispatch Console when you are not a part of an active call.

If you are idle and a one to one or camped group call starts the call details are shown on the *Call Activity Window*. The group name for a one-to-one call is shown as “None”.

---

**Note:** There is no call ready screen displayed at the call activity window. You will join the call immediately

**Note:** You will automatically join the group call only if camped on the group. If the group is not camped and a group call is initiated, you will receive a group missed call alert at the end of the group call.

---

## 5.4 PTT Call Behavior While the Dispatch Console is in the Background

During a PTT call, if you navigate away to another application, you will continue to hear the PTT call. In order to take the floor and speak on the call, you must navigate back to the PTT Dispatch Console to use the PTT button or you can use selected accessories to take the floor.

## 5.5 Rejoining a Group Call

If you drop from a group call e.g. using the End Call button, you can re-join the call by initiating a call to that group. You can call the group from the call logs history, monitored groups or from the Groups tab.

---

**Note:** If the call ended before you try to re-join, you will start a new call to that group.

---

# 6. Using the Map

The PTT Dispatch Console uses the Google map service to display the location of fleet members on a map.

---




**Note:** To locate a fleet member, the fleet member must be listed and assigned in the Dispatcher's groups and contact list through the Corporate Admin Tool (CAT). In addition, the GPS feature must be enabled on the fleet member's phone.

It is recommended that the mobile PTT devices being located are Android or iOS smartphones and running the latest PTT App.


---

## 6.1 Locating

### Locating single/multiple fleet member(s)

1. Click **Contacts Tab** from **Contacts and Groups Window**.
2. Select contact(s) by clicking the checkbox next to the fleet member's name.
3. Click the  icon to locate the selected fleet member on the map. When the fleet member(s) is located on the map, a marker  is displayed at the fleet member's location.
4. Click on the  marker to view information for the fleet member(s).


---

**Note:** If location information is expired for the fleet member, then the fleet member will be located on the map with  icon..


The color of the push pin indicated on the map, depends on the color set for Individual contacts, contacts belonging to a single group and common contacts between groups in Map Color Settings.

---

## 6.2 Clear located fleet members on the map

To clear all the located fleet members on the map, click on  icon provided at the top right corner of the map. To selectively clear the fleet members located on the map use selection list window. Select the fleet members by checking the check box on the selection list window.

## 6.3 Fleet Member Information Window

Click on the marker icon  located on map to display the fleet member information window.

## 6.4 To select multiple fleet members:

Press the Shift Key and holding the left or right mouse button, drag the mouse over the marker icons. The Selection List Window will appear as shown below displaying the fleet members you selected.

## 6.5 Finding an address

Mouse over on the map menu and click Find Location. This will display a *Find Location Map Window* .

---

**Note:** To hide or display the find location window, mouse over on the map menu and select Find Location option.

---

## 6.6 Auto tracking a fleet member

The Auto Tracking feature is available in Edit Map Setting. When enabled, the map zooms in and out and centres itself automatically to make sure that all the located fleet members are displayed on the map.

If this feature is disabled in the Edit Map Settings, you will have to scroll the map to find them when they go out of the map coverage area or re-locate them to bring them in the view.

---


**Note:** Auto Track feature is disabled by default and needs to be enabled if required from Edit Map Settings.

---

# 7. Recording Calls

## 7.1 Full Session Recording

Full Session recording allows you to record each call you join. All the calls you are participate in will be recorded. In Full Session recording mode, the following behavior is observed for a call:

1. The **recording** status is indicated by the record icon  on the **Call Activity Window**
2. When the call ends, the call recording is created and automatically stored in the call history. When next call starts the call is automatically recorded and stored as new entry.

---

**Note:** Only those calls are recorded where you are the participant of the call.


---

## 7.2 Manual Recording

Manual recording allows recording whole or part of the call, by using start and stop record button whenever recording is desired.

1. Click the Record icon  to start recording the call



2. Click the record icon  again to stop recording. A recording entry is made in the call logs.

---

**Note:** During a call if the recording setting is changed, it will be applicable from the next call.

---

## 7.3 Playing Back Recorded Calls

Recorded calls are stored under **Call Logs**.

### To view recorded calls

1. Click **Logs>Call Logs**. Refresh to view the latest information.
2. Select a recording from the Call Logs section, and click the Play button to play the recorded files.


## 8. Alerts

Alerts can be a request from a fleet member for a call or a notification that you missed an incoming PTT call. Alerts are displayed in the **Alerts Window**. You can respond to an alert with an action (locate, call, or send IPA). Alerts also have a status (Attended, Unattended, Parked, or Complete). Alerts can be sorted by Sender's name, Time, Type or Status by clicking on the column label. By default, the Alerts will be sorted by Time. This section describes alerts.


### 8.1 Instant Personal Alerts (IPA)

An Instant Personal Alert (IPA) is a way for a fleet member to ask for a call back from you or vice versa. An IPA is especially useful if the fleet member you want to call has a presence status of Do Not Disturb.

#### 8.1.1 Sending an Alert

1. Click on **Contacts Tab** from the **Contacts and Groups Window** and select a fleet member using the checkbox next to the member's name.
2. Click the IPA  icon. When the IPA is sent, a message appears at the bottom right-hand part of the screen with the status showing "Success" as shown below:

#### 8.1.2 Receiving an Alert

Whenever an Instant Personal Alert is received, it will be shown in the Alerts Window with the IPA icon  next to the name of the sender. From this window, you can return a call.



## 9. Monitoring Groups

The PTT Dispatch Console allows you to monitor up to sixteen groups via the Monitored Groups Activity window. When monitoring, you will be able to see call activity on monitored groups and optionally join a group call if active. This is helpful when you want to be aware of the call activity on specific groups but not necessarily want to participate immediately.

The Monitored Groups Activity window also allows the dispatcher to enable Talkgroup Scanning.

---

**Note:** Local groups cannot be monitored.


---

## 9.1 Adding a Group to Monitored List


To add a group to monitored group list, follow these steps:

1. Click on the Groups Tab in the Contacts and Groups Window.
2. Find the group you want to monitor and select the group by clicking the checkbox next to the name or by highlighting the group.
3. Drag and drop the group from Groups tab of Contacts and Groups window to the Monitored Groups Activity Window. When group is successfully added, then the icons for Call, Close, Camped off and Locate are enabled and the name of the monitored group is shown.

The following figure shows an example of the Monitored Groups Activity Window:



## 9.2 Removing a Group from Monitored List

Click on the remove group  icon to remove the monitored group from the *Monitored Groups Activity Window*.

---

**Note:** You can remove a group from monitored list only if there is no call in progress for that group. A camped group cannot be removed.


---

**Note:** You can replace a group from monitored list only if there is no call in progress for that group

---



## 9.3 Actions on Monitored Group

Once the group is monitored, the call status indicator provides feedback on group call activity. When a group call starts the call status indicator turns green and starts blinking,




also the monitored group area background turns grey indicating that you have not yet joined the call. Once you join the call the background of the monitored group area turns green and the blinking of the status indicator stops.

### Joining an active group

If the call is already started, you can join the call by clicking the  icon. The call status indicator will turn  and you will begin to hear the conversation. During the call use the **Call Activity Window** to make a PTT group call.

---

**Note:** When you try to join an ongoing active group call by clicking the  icon, call ready screen is not displayed at the call activity window. Instead you readily join the group call, if the floor is available you will get the floor and lose the floor momentarily while a floor taken/busy tone is played. If the floor is not available you hear a bong tone indicating that the floor is unavailable and being used by a fleet member.

---

### Placing call to a non active group

You can place a call to a Monitored Group not currently on a call by clicking on  icon.

### Locating group members from Monitored Groups

You can locate all the members of the monitored group on map by clicking on  icon.

# 10. Talkgroup Scanning

Replacing the Talkgroup Select or “Camping” functionality, Talkgroup Scanning enables a PTT user or a Dispatcher to monitor (or scan) activity and communicate with a subset of up to 16 corporate groups. This subset of corporate groups is also known as a scan list. Scan lists are usually maintained and pushed out to devices by a CA by the CAT, but Talkgroup scanning management functionality is available from the handset as well.


When a call is active on a group within the scan list, the PTT user/Dispatcher automatically joins that call and can participate. When the call ends, the PTT user joins the next active call in progress from the scan list.

PTT users/Dispatchers can also set Priority levels to groups within the scan list. Priority Group Scanning is a Talkgroup Scanning feature that allows you to designate up to 3 groups with Priority levels 1 (highest) through Priority 3 (lowest):

- Each priority group can only have one single group assigned to that priority
- Calls on a higher priority group pre-empt calls on a lower priority group
- Calls from any of the priority groups pre-empt non-priority calls in the monitored groups list

## 10.1 Adding Monitored Groups to Talkgroup Scan List


Once you have at least one group in your monitored list (as described in section 9), each desired group must be added to the Talkgroup Scan list before Talkgroup Scanning can be enabled.


**To add Monitored Groups to the Talkgroup Scan list**, select the “Set Group Priority”  button and pick one of four options presented: No Priority, Priority 1, Priority 2 or Priority 3. Once selected, the “Set Group Priority” icon will change depending on the option selected:

No Priority:  Priority 1:  Priority 2:  Priority 3: 

# 10.2 Enabling Talkgroup Scanning


Once priority levels are assigned and Monitored Groups have been added to the Talkgroup Scan list, Talkgroup Scanning can be enabled by selecting the Talkgroup Scanning button


 located on the top right hand side of the Monitored Groups Activity Window:



**Note:** When Talkgroup Scanning is on, calls from any of the monitored groups not on the scan list are not delivered and any calls on the Scan list will be heard immediately.

# 10.3 Turning Talkgroup Scanning Off

Talkgroup Scanning can be turned off by simply selecting the Pause button  on the top right hand corner of the Monitored Groups Activity Window:



# 11.Using the Map

The Dispatch Console uses the Google map service to display the location of fleet members on a map.




---

**Note:** In order to locate a fleet member, the fleet member must be a member of one of the Dispatch groups assigned to the Dispatcher through the Corporate Admin Tool (CAT). In addition, the GPS feature must be enabled on the fleet member's phone.


On first time login to the PTT Dispatch Console, no contacts will be located on the map. You have to locate contacts using the below steps. From the next login, you will see the last located contacts on the map.

---

## 11.1 Locating single/multiple fleet member(s)

1. Click on the **Contacts Tab** from the **Contacts and Groups Window**.
2. Select contact(s) by clicking the checkbox next to the fleet member's name.
3. Click the  icon to locate the selected fleet member on the map. When the fleet member(s) is located on the map, a marker  is displayed at the fleet member's location.
4. Click on the  marker to view information for the fleet member(s).

---

**Note:** If location information is expired for the fleet member, then the fleet member will be located on the map with  icon..


The color of the push pin indicated on the map, depends on the color set for Individual contacts, contacts belonging to a single group and common contacts between groups in Map Color Settings. For more details refer the section "[Map Settings](#)"


---

**Note:** In order to locate a group member, the member must be listed in the contacts list.


---

# 11.2 Fleet Member Information Window


The Fleet Member Information Window appears when selecting a fleet member's marker  from the map. Dispatchers can obtain information such as the fleet member's presence status, location and last location refresh time. Dispatchers can also make a direct PTT call to that fleet member, send an IPA and refresh fleet member's location.



# 11.3 Clear all located fleet members on the map

To clear all the located fleet members on the map, click on  icon provided at the top right corner of the map. To selectively clear the fleet members located on the map use selection list window.

## 11.4 Managing fleet members

Once fleet members are located on the map, select the  to open the Selection List Window. Use the checkboxes located next to the contact names to:

- Send PTT calls to one or many fleet members on the map
- Send an IPA to one or many fleet members on the map
- Refresh location information of one or many fleet members on the map
- Remove one or many fleet members from the map





# 12 Real-Time Presence

Real-Time Presence allows you to quickly know whether the fleet member is available, busy (DND), or offline. Only fleet members with presence as available receive PTT calls. The Presence Indicator is displayed next to the name of each of your contact.

## 12.1 PTT Contact/Fleet Member's Presence

Presence of a contact can be seen in the contacts list indicated by an icon next to contact's name.

**Available:** The PTT contact is logged into the PTT application and ready to receive PTT calls and Instant Personal Alerts. It is shown with the *Green* presence icon.

**Do Not Disturb (DND):** The PTT contact is logged into the PTT application but does not want to be disturbed with incoming PTT calls. It is shown with the *Red* presence icon.

You can still send an Instant Personal Alert to DND Contact.

**Offline:** The PTT contact is logged out from the PTT application and will not be able to receive PTT calls and alerts. It is shown with a *Gray* presence icon.

## 12.2 Your Presence

Your presence is indicated on the PTT Dispatch Console screen as shown below.



# 13 Using Accessories

The Dispatch Console supports following audio devices and floor control devices.

1. Input Devices
  - a. External Microphone (1/8" jack)
  - b. Headset with PTT (USB)
  - c. Internal Microphone (supported by system hardware)
2. Output Devices
  - a. External Speakers (USB, 1/8" jack)
  - b. Headset with PTT (USB)
  - c. Internal Speakers (supported by system hardware)

## 13.1 Notification Message on Connection

The default device is set based on the order of plug-in. You can change audio input or output device from **Setting -> Devices**.

---

**Note:** If you do not see the notification, enabled/disable the accessory setting from your PC → Control Panel → hardware and Sound → Recording tab.

---

Changes made to default audio Input / Output devices during call take effect after the current call ends.

---

## 13.2 Using Headset

You can use a headset plugged into your laptop/desktop to initiate PTT calls, floor control and audio input/output.

---

**Note:** To control floor operations and call initiation process, the "Headset for PTT" needs to be selected in at least one of the audio input or audio output's preference under **Devices** tab under settings.

---

If any preferences of Audio (I/O) are changed during an ongoing call, they will be applicable from the next call.

---

When initiating a call from a PTT Headset follow the process below:

1. Select the contacts/Group/Local Group
2. Push the button on the Plantronics PTT Headset accessory/adaptor to initiate a PTT call or to perform the floor control operation. These devices, when connected are displayed under Settings > Devices in the PTT Floor Control field.

---

**Note:** - In Windows 7 Operating System to place a call or to perform floor control operation from this device, select "Headset with PTT" from either audio input or audio output drop-down list when connected.

---

## 13.3 Using Footswitch


The PTT Dispatch Console supports Foot Pedal for PTT floor control. When placing a call with this accessory connected:

1. Select the **Contacts/Group/Local Group**
2. Push the PTT Foot Pedal on the accessory to initiate a PTT call to perform the floor control operation. These devices, when connected are displayed under **Settings > Devices** in the **PTT Floor Control** field.


The PTT Dispatch Console dynamically recognizes these accessories when connected or removed from the system hardware.

# 14 Settings

PTT Dispatch Console provides a number of Settings that you can configure per your need.

Click **Settings** on the Dispatch Console. Select the individual expand  icon to view or modify the appropriate setting options.

## 14.1 Generic Settings



### 14.1.1 Alert Settings

Specifies how long alerts stay in the Alerts window. After the specified time, alerts are moved to Logs. Alerts can be configured to stay in the Alerts window anywhere from 12 to 24 hours after they are received.

### 14.1.2 Backup/Archive Settings

Backup/Archive Settings: allows you set up the following:

1. **Backup interval** - Determines how often backup is performed. You can back up from one day to seven days. If you do not change the factory setting then data will be backed up once a day.
2. **Archive Interval** - Determines the how often data is archived. You can archive from two days to eight days. If you do not change the factory setting then data will be archived once in eight days.

3. **Backup/Archival** - Determines at what time of the day the Backup / Archive process starts (Min: 00:00 hours Max: 23:00 hours). If you do not change the factory setting then data will be backed up/archived at midnight on the day of setting.
4. **Backup Path** - Sets the path on your PC where the Backup/Archived data is saved.
5. **Backup Target Space** - Specifies the max amount of space the application can use to save Backup/Archived data. At minimum you need 5GB of space. If you do not change the factory setting then max 5GB of space shall be used.

---

**Note:** Archival interval should be greater than or equal to backup interval.

---

### 14.1.3 Date/Time Format Settings

Using this setting, you can change how date and time is displayed on Dispatch Console. Supported Date formats are: MM/DD/YY and DD/MM/YY  
Supported Time formats are: HH:MM and HH:MM:SS

### 14.1.4 Recording Settings

Using this setting, you can change the call recording to either manual or full session. For more information refer to sections **Manual Recording** and

**Full Session** Recording **Error! Reference source not found..**

### 14.1.5 Application Settings

Allows you to set up diagnostics options e.g., showing exceptions and enabling log backup. This is helpful for bug fixes and products improvement. If another language is supported, it can be changed from within this setting.

Click the [Supported Feature Info link](#) to show the list of features that are enabled / disabled for ptt Dispatch Console UI. The enabled features are marked in Green ● and disabled features are marked with the Red ✖.

### 14.1.6 GPS Expiry Settings

GPS location of a fleet member is set to refresh automatically every 15 minutes by default. This refresh time can be reconfigured to refresh at a minimum of 15 minutes, to a maximum of every 120 minutes. If there is no location update after this set time, fleet member's location is marked as expired.

## 14.1.7 Report Settings

This setting allows you to set up the following:

Report Interval: reports can be generated and stored every day, every alternate day or three days once depending on the requirement.

Report format: The reports can be prepared in MS excel format.

Reporting Time of the day: The reporting can be chosen to be prepared within 24 hours during a specific time of the day.

Report path: The generated report is stored in a pre-specified path for future access to the reports.

You can generate reports in Excel format for specific instances (i.e. Alerts).

The columns in an Alerts report for example can provide information about:

- The type of Alert (Instant Personal Alert/One To One Missed Call Alert)
- Direction of Alert (Incoming/Outgoing)
- Name of the person (to whom the Alert was sent/ from whom the Alert has been received)
- Phone Number of the Alert (Sent/Received)
- Status of the Alert (Attended/Unattended/Parked)
- Time of the Alert sent/received

The columns in a Call report provides information about:

- The type of Call (One To One Call/Group Call)
- Direction of Call (Incoming/Outgoing)
- Name of the person (calling/called)
- Phone Number of calling/called fleet member/group
- Duration of call in minutes
- Time and Date of Call

The columns in a Location report provides information about:

- Name of the fleet member

- Phone Number of fleet member
- Presence status of the fleet member (Available/Offline)
- Latitude of the location
- Longitude of the location
- Time and Date of Call

The columns in the Audit Information report provides information about:

- Action Type
- Description of the action
- Time and Date of audit
- User machine identity on which the PTT Dispatch Console is running

## 14.1.8 Device Settings

Device settings drop down provides the dispatcher information about the devices used for audio input, output and PTT floor control.

## 14.1.9 Tones

This setting allows you to enable, disable and set call tones, alert tones and other tones.

Call Tones: Tones related to the call features

e.g.: Floor Acquired, Floor Busy, Floor Free and Incoming Call tones.

Alert Tones: Tones related to the Alert features

e.g.: Missed Call Alert and Instant Personal Alert tones.

Other Tones: Tones related to an operation/status notifications

e.g.: Pop-up Notification tones (Success or Error).

## 14.1.10 About

About provides the dispatcher with the Dispatch Console version number, data version, and map version. The End User License Agreement link is available here as well.

## 14.2 Map Settings

The Map tab is located under the Settings tab.


### 14.2.1 Map Color Settings

This section allows you to assign customized colors either for contacts and groups to be displayed on map. You can choose a color for a contact, groups and members belonging to multiple groups. If you wish, you can restore the colors back to default factory setting.

The chosen color push pin for the selected contact will be displayed on the map when you locate a specific contact or group on the map.

#### To set color for contacts:

This setting allows you to choose a color that will be used when a contact is located on the map. To set a color follow the below steps:

1. Click on the **Settings** tab, and then click on **Map Settings**.
2. A Map Color Settings window will be displayed.
3. Click on the **Default Contacts Color** and then click on the drop down which is displayed.
4. Select the new color, you wish to assign for a contact.
5. Click on **Apply** button at the bottom of the screen to **Save** the changes.
6. In the below screen shot selected contact's location is shown with  push pin on the map.

---

**Note:** All the contacts are shown in same color on the map.

---



### **To set default color for a group member:**

This setting allows you to select a default color for group members when no color is chosen for a group member:

1. Click on the **Settings** tab, and then click on **Map Settings**.
2. A Map Color Settings window will be displayed.
3. Click on the **Default Group Color** and then click on the drop down which is displayed.
4. Select the new color, you wish to assign for a group member.
5. Click on **Apply** button at the bottom of the screen to **Save** the changes.
6. When you locate a group member, the assigned color push pin will be appearing on map.

### **To set color for a Common Member in multiple group:**

This allows you to select a color for the fleet member who is part of more than one group.

1. Click on the **Settings** tab, and then click on **Map Settings**.
2. A Map Color Settings window will be displayed.
3. Click on the **Default Common Member Color** and then click on the drop down which is displayed.
4. Select the new color, you wish to assign for a common member.
5. Click on **Apply** button at the bottom of the screen to **Save** the changes.
6. When you locate a group member, the assigned color push pin will be appearing on map.

---

**Note:** If you attempt to set same color for both 'Group' and 'Common Member', you will get an error message and PTT Dispatch Console will not allow you to save the changes.

---

### To set color for a group:

This allows you to select a common color for all the fleet member in one group.

1. Click on the **Settings** tab, and then click on **Map Settings**.
2. A Map Color Settings window will be displayed.
3. Click on the Group list in **Group Color settings** and then click on the drop down which is displayed.
4. Select the new color, you wish to assign for a Group.
5. Click on **Apply** button at the bottom of the screen to **Save** the changes.
6. When you locate a group member only belonging to this group, the assigned color push pin will be appearing on map indicating the fleet members in this Group.

### Setting color to default contact color/default Group color for a group:

This setting allows you to change the color back to default contacts color or default group color for a group.

1. Click on the **Settings** tab, and then click on **Map Settings**.
2. A Map Color Settings window will be displayed.
3. Right click on any Group in **Group Color settings** to view the options “*Set to Default Group color*” and “*Set to default Contact Color*” as shown in below screens.
4. Select the option “Set to Default Group color” to change the assigned Group color to that of Default Group Color.

Select the option “Set all to Default Contact color” to change color of all the Groups, Default groups color and Default common Member color to that of Default Contacts Color.

## 14.2.2 On-Demand Location Settings

This section allows the dispatcher to set the interval of time that the dispatch console fetches location information of a fleet member. The interval of time is set to 5 minutes by default, but can be set at a minimum of 3 minutes to a maximum of 15 minutes.

The dispatcher can also configure the duration of time the dispatch console will continue to fetch a specific fleet member’s location information after initially determining a member’s location. By default, duration is set to 1 hour, but can be set at a minimum of 30 minutes to a maximum of 24 hours.