

LIST OF CODES

Nova & MxV4 remotes

CCE	0037	0623												
Celebrity	0000													
Celera	0765													
Champion	1362													
Changhong	0765													
Cineral	0451	0092												
Citizen	0451	0060	0030	0092	0056	0561	1672	1935						
Clarion	0180													
Coby	1538	1634	2306	2314	2315	2338	2340	2343	2344	2345	2350	2560	3202	
Commercial Solutions	1447	0047												
Concerto	0056													
Conia	1687													
Contec	0180													
Continental	2357													
Coradir	2844													
Craig	0180													
Croma	1011													
Crosley	0000	0054												
Crown	0180	0672												
Crown Mustang	0672													
Curtis	1200	1326	2352	2397	2466									
Curtis Mathes	0047	0054	0154	0451	0093	0060	0702	0030	0145	0166	1661	0056	1147	1347
	1959													
CXC	0180													
Cytron	1326													
Daenyx	0180	0672												
Daewoo	0154	0451	0092	1661	0623	0661	0672	1816						
Daytron	0180													
Dell	1264	1080	1178	1863										
Denon	0145													
Diamond Vision	1997													
Digistar	1565													
Digital Lifestyles	1765													
Disney	1665	2152												
Drean	0037													
DSE	1565													
Dumont	0017													
Durabrand	0463	0180	0178	0171	1034	1463	1665							

LIST OF CODES

Nova & MxV4 remotes

Kardon														
Harvard	0180													
Havermy	0093													
Helios	0865													
Hello Kitty	0451													
Hewlett Packard	1494	2540												
Himitsu	0180													
Hisense	0748	1314	1660	2098	2355	2419								
Hitachi	1643	1145	0145	0056	0679	0797	1345	1445	1904	2215	2431	2433		
Hitech	1814													
HP	1494	2540												
Hyundai	0849	1219	1814											
I-Inc	1746													
iLo	1463	1286	1394	1603	1665	1684	1990							
Infinity	0054													
Initial	1603	1990												
Innova	0037													
Insignia	1423	1564	0463	0171	2751	2432	2184	2088	2049	2002	1963	1892	1810	1785
	1660	1641	1517	1385	1326	1204								
Inteq	0017													
IRT	0451	1661												
ITT Nokia	0180													
IX	0877													
JBL	0054													
JCB	0000													
JCM	2256													
Jensen	0761	1299	1326	1933										
JVC	0463	0053	0650	0731	1253	1601	1774	1923	2264	2271				
KDS	1687													
KEC	0180													
Ken Brown	0236	0463	1321											
Kenia	0030	0082												
Kenwood	0030													
Kioto	0054													
KLH	0765	0767												
Konka	1385													
Kost	1262	1483												
Kreisen	0876													
KTV	0180	0030												
LG	1423	1447	0017	1265	0178	0030	2834	2731	2424	2359	2358	2182	1993	1860

LIST OF CODES

Nova & MxV4 remotes

Olevia	1610	1144	1240	1331										
Onwa	0180													
Optimus	0250	0154	0166	0650	1924	1927								
Optoma	1348													
Optonica	0093													
Orion	0236	0463	1463	1938										
Otic	1687													
Packard Bell	0092													
Panasonic	1480	0250	0051	0650	1271	1291	1345	1924	1927	1941	1946	1947	2240	2264
Panavox	0861													
PARK	2104													
Penney	0047	0156	0051	0060	0178	0030	1347							
Petters	1523													
Philco	0054	0451	0463	0030	0145	0171	0092	1661	0082	1271	1394	1665	1963	
Philips	1454	1866	0054	0171	0037	0690	1394	1455	1483	1744	1806	1867	1961	2372
	2374	2564												
Pilot	0030													
Pioneer	1457	0166	0679	0866	1260	1398	2240							
Planar	1288	1589												
Polaroid	1523	0765	2425	2121	2117	2063	2002	1992	1769	1767	1766	1763	1762	1687
	1565	1538	1385	1341	1327	1326	1316	1314	1286	1276	1262	0865		
Portland	0451	0092	1661											
Precision	1792													
Prima	0761	0783	1749	1753	1785	1933								
Prism	0051													
Proscan	1447	0047	0030	1347	1922	2147	2183	2256						
Proton	0178													
Proview	1687													
Pulsar	0017													
Punktal	2687													
Pye	0412													
Pyle	1200													
Quasar	0250	0051	0650	1291	1924	1927								
RadioShack	0047	0154	0180	0178	0030	0056	1904							
RCA	1547	1447	0047	0051	0093	0060	1661	2932	2746	2434	2247	2187	2002	1959
	1958	1953	1922	1781	1347	1147	0679							
Realistic	0154	0180	0178	0030	0056									
RevolutionHD	1623													
Runco	0017	0030	1398											
Sampo	1755	0030	0762											
Samsung	0812	0060	0702	0178	0030	2814	2697	2596	2137	2103	2051	1959	1060	0814

LIST OF CODES

Nova & MxV4 remotes

Magnasonic	0651													
Magnavox	0503	0539	0646	0675	1354	1506	0035	0039	0081	0000	1593			
Magnin	0240													
Marantz	0539	2414	0035	0081										
Marta	0037													
Matsushita	0035	0162												
Media Center PC	1972													
MEI	0035													
Memorex	0695	0831	1270	2213	2331	3153	0035	0162	0037	0048	0039	0047	0240	
MGA	0104	0046												
	0240	0043												
MGN Technology	0240													
Microsoft	0522	2083	1972											
Mind	1972													
Minolta	0042													
Mintek	0717													
Mitsubishi	1521	0067	0043											
Motorola	0035	0048												
MTC	0240													
Multitech	0000													
NAD	0741													
NEC	0104	0067												
Nesa	0717													
Nikko	0037													
Niveus Media	1972													
Noblex	1233	0240												
Norcent	1107	1461												
Northgate	1972													
Olevia	2331													
Olympus	0035													
Onkyo	0503	1769	0627	1627	2147	2215								
Oppo	0575	2185	2545											
Optimus	1062	0162	0037	0048	0104									
Orion	0695	0184												
Oritron	0651													
Panasonic	0490	0503	0703	1579	1641	1062	0035	0162	0614	0616				
Penney	0035	0037	0240	0042										
Pentax	0042													
Philco	0675	0690	0733	0790	0862	0035								
Philips	0503	0539	2056	2084	0646	0675	1158	1340	1354	1506	2434	0739	0035	0081

LIST OF CODES

Nova & MxV4 remotes

Voodoo	1972												
Voxson	1630												
Vtrek	2587												
Wards	0060	0035	0048	0039	0047	0081	0033	0240	0045	0000	0042	0046	
WB Electronics	2555												
Xbox	0522	2083											
XR-1000	0035												
X-View	1233												
Yamaha	0490	0539	0646	0545	0497	0817	1354	2298					
Zenith	0503	0591	0741	0869	0037	0039	0033						
ZT Group	1972												

BLU-RAY PLAYERS

Denon	2258	2748											
Harman/ Kardon	2927	3228											
Insignia	0675	2428	2596										
Integra	2147												
JVC	2365	2855											
Lexicon	2545												
LG	0741	1602											
Magnavox	0675												
Marantz	2414												
Memorex	2331												
Olevia	2331												
Onkyo	2147												
Oppo	2545												
Panasonic	1641												
Philips	2084	2434											
Pioneer	0142	2442	2854										
Samsung	0199												
Sharp	2250												
Sony	1516												
Sylvania	0675												
Toshiba	2705	3157											
Viore	2553												
Vizio	2563												
Yamaha	2298												

AUDIO SYSTEMS

LIST OF CODES

Nova & MxV4 remotes

Aiwa	1405	0189	1388	1641										
Alco	1390													
Altec Lansing	2720													
AMC	1077													
Anam	1609													
Apex Digital	1257	1430	1774											
Apple	1115													
Arcam	1189	0189												
Audio-tronic	1189													
Audiovox	1390													
Bose	1629	1933												
Carver	1189	0189												
Coby	1389	2127												
Curtis	1389													
Daewoo	1250													
Denon	2706	2857	1360	1460	2247	2279	2516	2820	2987	3001	2502			
Dynex	2971													
Fisher	1801													
Gateway	1517													
Harman/Kardon	0892	3045	0110	0189	1304	1306	2241	2443						
Hitachi	1801													
HitPlus	2483													
iHome	2435													
iLive	2013													
Insignia	1030	1077	1751	1893	2126	2169	2175	2472	2929	2966				
Integra	1298	1320	1805											
iSymphony	2442													
JBL	0110	1306	2241											
JVC	1374	1495	1871	2040	2239	2331	2969							
Kenwood	1313	1569												
KLH	1390	1428												
Koss	1366	1497												
Left Coast	0892													
LG	1293	2197	2284	2676										
Linn	0189													
Liquid Video	1497													
Magnavox	1189	1269	0189	1514	1831									
Marantz	0892	1892	1189	1269	0189	1289	2114							

