

USING THEMES

THEMES AND SEARCH

You can list and choose programs by the theme of their contents (for example, just movies or just sports). You can then quickly list programs based on that theme, and choose the program you want.

Remote Buttons

Menu Options

1. To open the **Themes** menu, press the LEFT ARROW button or press MENU and then select **Themes**.



2. Move through the Themes menu by using the ARROWS. You can also move a page at a time using PAGE UP or PAGE DOWN.



3. Highlight the desired program in the program list.

4. Press the SELECT button to watch the program.



Note: If the program you highlighted is on some time in the future, the receiver will open the **Create An Event Timer** menu. See page 3-15 for information on using timers.