

RESETTING TO FACTORY DEFAULT SETTINGS

Note: Resetting the receiver to factory default settings discards all **Favourite Lists** except the **All Chan** and **All Sub** lists.

Note: If you have set any locks on the receiver, and the receiver is locked, these locks will be kept. If the receiver is unlocked, any such locks will be lost; however, you cannot reset the receiver to factory default settings to bypass a lock or to discard a password you have forgotten. Call the Customer Service Center if you have forgotten your password.

Complete the following instructions if you want to reset the receiver to be the same as when it was shipped from the factory.

Using The System Changing Program Languages

3

Remote Buttons

Menu Options

1. Press the Menu button.
2. Select the **System Setup** option.
3. Select the **Factory Defaults** option. When the receiver displays a **Warning** message, confirm that you want to reset the receiver to factory default settings.

MENU



mno



mno

