











To set the remote back to control the TV volume:

	Remote Buttons	Menu Options
1. Press and hold the TV mode button for three seconds, and then release it. The TV mode button will blink.		
2. Press the Pound (#) button.		
3. Press the plus (+) side of the Volume button.		
4. Press the 0 number button.		
5. Press the Pound (#) button. The TV mode button flashes three times.		
6. Press the sat mode button.		
7. Press the plus (+) and minus (-) sides of the volume button. The TV's volume changes and the TV mode button lights instead of the AUX mode button.		

TESTING THE SYSTEM

STARTING A TEST

	Remote Buttons	Menu Options
1. Press the Menu button.		
2. Select System Setup .		
3. Select Diagnostics .		



TELEPHONE CONNECTION TEST

This test checks that the receiver telephone connection is correct. Select the **Connection** option to begin the test. The receiver displays a message asking you to wait until the test is done.

- If the telephone connection is correct, the receiver displays a **Phone Connection** OK message.
- If the receiver highlights the **Done** option, select the **Dial Out** option so the receiver can make a toll-free call to the Customer Service Center. The receiver displays a message asking you to wait until the call is done. When the call is done, select the **Done** option to exit the test menu.
- If the telephone line is not connected properly, the receiver displays a failure message. In this case, check the telephone connection and then repeat the test.

Note: If you have the receiver connected to a DSL (Digital Subscriber Line) phone line, it may cause this test to fail. If so, you will need to install a DSL filter between the receiver and the phone jack on the wall. You should be able to get a DSL filter from your DSL provider, or your local electronic parts store.