

LG-C900B User Guide - English




- **This guide helps you to start using your phone. If you need more information, please visit www.lge.com/ca.**
- Some of the contents of this manual may not apply to your phone depending on your phone's software or your service provider.
- This handset is not recommended for the visually impaired because of its touch-screen keypad.
- Copyright ©2010 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.



Congratulations on your purchase of the advanced and compact LG-C900B phone by LG, designed to operate with the latest digital mobile communication technology.

Copyrights and trademarks

Rights to all technologies and products that comprise this device are the property of their respective owners:

- This product includes software licensed from  Windows Phone MS, an affiliate of the Microsoft Corporation. Microsoft and software bearing the Microsoft name are registered trademarks of the Microsoft Corporation. Before using this product, refer to the MICROSOFT SOFTWARE LICENSE TERMS FOR WINDOWS PHONE 7 SOFTWARE Agreement at the back of this guide for information about rights and restrictions.
- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc.
- © 2010 Microsoft Corporation. All rights reserved. Microsoft, Internet Explorer® Mobile, Windows® Phone, Windows® Phone Marketplace, Xbox LIVE®, Zune®, are trademarks of the Microsoft group of companies.

Contents

Assembling	5	Personal Information	47
Getting to know your phone.....	5	People Hub	47
Open view.....	6	Me card.....	48
Slide Out QWERTY Keyboard	7	Calendar	49
Installing the USIM and battery	8	Office.....	49
Navigating Windows Phone	10	The Web	54
Turning the Phone On and Off	10	Internet.....	54
Using your Touch screen	10	Maps.....	56
Getting to know your Start screen.....	13	Marketplace.....	58
Customizing Start Screen.....	15	Connectivity	59
Viewing the status bar	16	Bluetooth	59
Navigating and Setting Applications	18	Wi-Fi	60
Customizing your Windows Phone	21	Play To.....	61
Enter text.....	22	Utilities	63
Download applications from Marketplace	23	Alarms.....	63
Getting started	25	Calculator	63
Step 1. Sign in with a Windows Live ID.....	25	Search.....	63
Step 2. Import your contacts	26	Settings	64
Step 3. Stay in Sync.....	26	System Settings	64
Communication	27	Applications Settings	65
Phone.....	27	Software update	68
Messaging	29	Phone Software update.....	68
Email	30	Accessories	69
Facebook.....	33	For Your Safety	70
Entertainment	34	Safety Guidelines	74
Camera.....	34	FAQ	88
Pictures	38		
Music & Videos	41		
Games.....	44		
FM Radio	45		

Assembling

Getting to know your phone

Headset Jack

Power/Lock key

- Long press (5 secs) for Power ON / OFF.
- Short press to turn the screen on or off.



Speaker Mic.

Allows other callers to hear you during a call, Voice recording or Voice Command.

Earpiece

Lets you hear the caller and prompts.

Proximity sensor

Search Button

Open Quick Search

Start Button

Return to the Start screen;
Start the Voice Recognition function (press and hold).

Back Button

Returns to the previous screen.

Mouthpiece



WARNING:

Putting a heavy object on the phone or sitting on it can damage its LCD and touch screen functionality. Do not cover protective films as this may cause the sensor to malfunction.

Assembling

Charger, Data cable (USB cable)

TIP: Before connecting the USB cable, wait until the phone has powered up and been registered on the network.



Volume keys

- **When the screen is idle:** volume of system tone & ring tone.
- **During a call:** earpiece volume.
- **When playing a track:** controls track volume.


Camera key

- Go to camera preview directly by pressing the camera key when on homescreen.

Open view

External camera lens

Camera Flash



Battery cover

Battery

USIM Card Tray

Slide Out QWERTY Keyboard



- 1 **Caps Button** lets you enter capital letters.
- 2 **fn Button** lets you enter alternate characters such as @ (using the A button). To lock the fn button, press the fn button. To unlock the button, press it again.
- 3 **Language(🌐)/Symbol Button** lets you change the language, or enter symbol mark.
- 4 **Space Button** enters spaces when in a text entry field.
- 5 **Delete Button** deletes a single space or character with each press. Press and hold to delete text more quickly.
- 6 **Enter Button** moves the cursor to the next field or text line.

- 7 **Directional Buttons** scrolls through the menu items and highlights a specific field or object by pressing up, down, left or right.

NOTES:

- All screen shots in this guide are simulated. Actual displays may vary.
- Instructions to perform tasks in this guide are based on the default phone settings and may change depending on the software version on your phone.

Assembling

Installing the USIM and battery

1 Remove the battery cover

Place your thumbnail in the cover opening. Open the cover as pictured below.



2 Remove the battery


Using the cut-out at the bottom, lift it from the battery compartment.



⚠ WARNING: Do not remove the battery when the phone is switched on, as this may damage the phone.

3 Install the USIM card

The USIM card should be inserted with the gold-coloured contacts downwards towards the phone, and the notch in the USIM pointing to the bottom of the phone.



4 Install the battery

First, insert the top of the battery into the top edge of the battery compartment. Ensure that the battery contacts align with the phone's terminals. Press the bottom of the battery down until it clips into place.



5 Close the battery cover

Align the cover hook to the latch as pictured below. Close the cover in the direction of the arrow.



Charging your phone

Open the charger socket cover on the side of your LG-C900B. Insert the charger and plug it into a mains electricity socket.



When the battery is fully discharged, you can not power on the phone. It takes approximately 4-5 minutes to reach a charge state sufficient for booting. It takes 14-15 minutes more for charging by USB connection.

If the battery is critically low, image for the critical low battery will be shown and notify user to charge more time.

NOTE: The battery must be fully charged initially to improve battery lifetime.

WARNING: Do not connect the charger to the phone without the battery. You must check the battery is inserted before charging.

WARNING: Do not remove your battery or USIM card while charging.

WARNING: There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries in accordance with the maker's instructions.

WARNING: Unplug the charger from the power socket during lightning storms to avoid electric shock or fire.

WARNING: Make sure that no sharp items come into contact with the battery. This could pose a fire risk.

Navigating your Windows Phone

Turning the Phone On and Off

Turning the phone on

- 1 Press and hold the [Power/Lock] button for a couple of seconds.

NOTE: When you turn on your phone for the first time, essential settings are going to be guided. Please follow the instructions on the screen to activate your device.

Turning the phone off

- 1 Press and hold the [Power/Lock] button.

Using your Touch screen

Touch screen tips

Your device's touch screen lets you easily select items or perform functions. Learn basic actions to use the touch screen.

NOTES:

- To avoid scratching the touch screen, do not use sharp tools.
- Do not allow the touch screen to come into contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.
- Do not allow the touch screen to come into contact with water. The touch screen may malfunction in humid conditions or when exposed to water.
- For optimal use of the touch screen, remove the screen protection film before using your device.
- Your touch screen has a layer that detects small electrical charges emitted by the human body.

- For best performance, tap the touch screen with your fingertip. The touch screen will not react to touches of pointing tools, such as a stylus or pen.
- Your device turns off the touch screen when you do not use the device for a specified period. To turn on the screen, press [Power] button.
- You can also adjust the backlight time or change wallpaper. In the Start screen, go to the application list and select **Settings > lock & wallpaper**.

Universal gestures on your touch screen

For most applications, natural gestures can be used to move about and give commands. For typing text, use the onscreen or the hardware keyboard.

The following gestures will be used to move around for your Windows Phone7:

Tap

A tap is a single, quick downward touch on the screen. Tap is used to execute commands (like pressing Enter on a PC). Tapping also stops any movement on the screen.



Double Tap

A double tap is two quick downward touches on the screen in the same place. The double tap commands the phone to zoom in or out, as appropriate.



Touch and Hold

To touch and hold, the finger is pressed down and held there for a few seconds.



Pan

A pan is a single finger placed down and moved across the screen in any direction. The pan gesture ends when the finger is lifted from the screen. Either the content will follow (as with moving a map into the center of the screen) or it can be used for reordering items (for example changing location of tiles on the Start screen).



Navigating your Windows Phone

Flick

A flick is a single finger down moved rapidly in any direction and ends with the finger up. A flick can follow a pan gesture.

A flick gesture moves content from one area to another area. The controls or the application can be configured to support specific flicking directional behavior. This can be horizontal, vertical, or another specified direction. If horizontal or vertical paths are specified, movements in other directions will be converted into vertical or horizontal movement.



Pinch and Stretch

Pinch and stretch are opposites of each other. These gestures are used often with maps when zooming in and out. Pinching is achieved by moving two fingers downward on the screen and bringing them together. This zooms in on content, while centering the image to the center of the fingers. For stretching, the fingers are moved down and away to zoom out on an image.




Getting to know your Start screen

From this screen you can access menu options, make a call, view the status of your phone and much more.



Knowing and navigating the Start

Start is the beginning of the Windows Phone 7 experience for users after they power on their phone. Start displays application tiles that users have pinned and placed in a position of their choosing for quick launch. Pressing the [Start] Button  on the phone always returns a user to Start, no matter what application is running.

1 Simply swipe your finger up or down to view them.









You can also customize tiles on the Start screen, which are shortcuts to your favourite menus or applications.




NOTES: When you are in a standby display after unlocking the phone, swipe your finger upward, then you can see the start screen displaying application tiles.

Navigating your Windows Phone

Tiles on Start screen

A tile is a visual shortcut for an application or content that users can set in an arbitrary location on the phone Start screen. Tiles that use the tile notification feature can update the tile graphic or title, or increment a counter, enabling users to create a personalized, “glanceable” Start experience. Start is always presented in portrait view.

Icon	Description
	Make calls, obtain quick access to recent callers, favorites, and all of your contacts. Dial manually using the numeric keypad. Tap the voicemail icon to listen to voice messages that you want, in any order you like.
	Touch to access people hub—the integrated communication application for emails, messages, contacts and other information.
	Send and receive SMS text messages. Conversations are saved in a conversation-like presentation, so you can see the history of messages that you have sent and received. Send MMS messages with pictures you have taken.
	Windows Phone works with Microsoft Exchange, Microsoft Outlook Web Application, and many popular email systems—including Hotmail, Yahoo! Mail, Google and other email.
	Touch to stream videos, music, and pictures from your phone to a Digital Living Network Alliance (DLNA) compatible device.
	Enter events in your new Windows Phone. Subscribe to calendars. Set alerts to remind you of events, appointments, and deadlines. Everything is synced with your calendar on Windows Live.
	Touch to access the Internet Explorer.
	Access Xbox Live to play games and to invite a friend to play a game with you. Download new games onto your phone.

Icon	Description
	View photos and videos that you have taken with your new Windows Phone, received in Email or MMS messages, or synced from your computer's Zune Software (Windows OS only). View photos in portrait or landscape format. Zoom in on photos for a closer look. Send an email or MMS messages with photos. Also able to view and upload Facebook photos.
	Music/Video player – plays music, videos, or podcasts. Plus, you can also listen to music and news on the FM radio. Listen to music while you surf the web or check your email, catch up on your favorite podcasts on your commute. If you don't have music, videos, or podcasts on your phone yet, you can sync files with your phone or obtain from the Marketplace. (Marketplace may not be available in some countries or regions.)
	The Marketplace is an online store (accessible from your phone) where you can try, buy, and search for apps, music, and game. Please note that the Marketplace is not available in all countries/regions.

NOTES:

- Arranged location, name, or design of Tile may vary by your setting status, area, phone carrier, plan, and version of Windows Phone software.
- Application functionality and availability may vary depending on the country or region where you purchase and use Windows Phone. Contact your carrier for more information.


Customizing Start Screen



You can customize the layout of Tiles on the Start screen.

You can pin all sorts of things to Start, including apps, websites, map locations, and even contacts. When you pin a contact to Start, you'll get all of that person's feed updates—right from that tile.

To pin most things to Start, touch and hold the item until the menu appears, or open the app list, then tap **pin to start**.

- If you'd like to move a tile somewhere else on Start, touch and hold the tile, and move it wherever you'd like it.
- To remove a tile, touch and hold it, and tap unpin .

Navigating your Windows Phone

Viewing the status bar

The status bar uses different icons to display phone information, such as signal strength, new messages, battery life, and active Bluetooth and data connections.

Below is a table explaining the meaning of icons you're likely to see in the status bar.



1. Cellular signal strength
2. Cellular data connection
3. Call forwarding
4. Roaming
5. Wi-Fi connection
6. Bluetooth device
7. Phone profile
8. Input language and method
9. Battery
10. Clock

[Status bar]

1. Cellular signal strength

	Very high signal strength
	High signal strength
	Medium signal strength
	Low signal strength
	Very low signal strength
	Extremely low signal strength
	No signal
	Airplane mode.
	SIM card is missing.
	SIM card is locked.


Notes:

- The cellular data connection icons might look different on your phone and can vary by mobile operator.
- While in Airplane mode, Cellular, Wi-Fi, and Bluetooth connections are all turned off simultaneously. (However, you can still turn Wi-Fi and Bluetooth on separately.)


2. Cellular data connection


G	GPRS
1X	RTT
DO	EVDO
E	EDGE
3G	3G
H	HSDPA/HSUPA
DV	EVDV
W	WIMAX
L	LTE

3. Call forwarding






 The call forwarding is turned on.

4. Roaming


 Your phone is roaming and not on your home cellular network.

Note: The Roaming  icon might look different on your phone and can vary by mobile operator.



5. Wi-Fi connection

	Connected to a Wi-Fi network with a very high signal strength.
	Connected to a Wi-Fi network with a high signal strength.
	Connected to a Wi-Fi network with a medium signal strength.
	Connected to a Wi-Fi network with a low signal strength.
	Wi-Fi is turned on, but your phone isn't connected to a Wi-Fi network.













6. Bluetooth device

 Bluetooth device is connected to your phone.

7. Phone profile

	The phone is in Vibrate mode.
	The phone is in Silent mode.




Navigating your Windows Phone

8. Input language and method	
	Shift is on.
	Shift Lock is on.
	Fn is on.
	Fn Lock is on.
DE	German (DE)
EN	English (EN)
ES	Spanish (ES)
FR	French (FR)
IT	Italian (IT)
9. Battery	
	Battery is charging.
	Phone is plugged in and battery is fully charged.
	Full battery power
	High battery power
	Medium battery power
	Low battery power
	Critically low battery power and needs to be charged.
	Battery power or state of the battery isn't known at the current time.
10. Clock	
The clock displays the current time.	

Navigating and Setting Applications

Access applications

To access your Windows Phone's applications,

- 1 On the Start, Tap the arrow  to access the application list.
Or, on Start, flick left to the application list.
- 2 Pan down to the tile if it isn't already visible.
- 3 Select an application.
- 4 Press the **Back** button  to return to the previous screen; Press the **Start**  button to return to the Start screen.



NOTES:


- You can add a shortcut to an application by tapping and holding the application icon and selecting "pin to start" from the option list that appears. You can move the application to the location you want on the Start screen.
- Your Windows Phone has a built-in motion sensor that detects its orientation. If you rotate the device while using some features, the interface will automatically switch between landscape and portrait view.

Getting to know the application bar

To set the application, you can use the below application bar and application bar menu.

For example, to read a message

- 1 On the Start screen, Tap the arrow  to access the application list.
- 2 Tap **Messaging** .
- 3 Tap the **•••** to expand the application menu and see the text labels for the icons in the application bar.
- 4 Select the icon button or menu which you want to use.



Application bar menu

The Application Bar Menu is an optional way for users to access specific tasks from the Application Bar. The Application Bar Menu can be accessed by tapping the visual indicator of sequential dots in the Application Bar or by flicking the Application Bar up. This view can be dismissed by tapping outside of the menu area or on the dots, using the back button, or selecting a menu item or Application Bar Icon.

NOTES:

- If no menu items are displayed, only the icon text hints are displayed.
- The Application Bar Menu will remain on the screen until the user performs an action.

Navigating your Windows Phone

Application bar icons

The following are some of the icons for the application setting that are frequently used.



NEW



ADD



remove/minus



CONFIRM



CLOSE



CANCEL



SYNC



REFRESH



QUESTION MARK



EXCLAMATION



BACK



NEXT



SEARCH



DELETE



SAVE



FOLDER



VIDEO



CAMERA



E-MAIL



SETTINGS



FAVORITES



ADD TO FAVORITES



DOWNLOAD



UPLOAD



SHARE



EDIT



EXPAND MENU



PLAY



PAUSE



PREVIOUS/REWIND



NEXT/FASTFORWARD

Customizing your Windows Phone

Get more from your device by customizing it to match your preferences.

Set the current time and date

- 1 In Idle mode, open the application list and select **Settings > System > date & time**
- 2 Tap **Set automatically** bar and change the date and time and other options.

Turn on or off the ringtone and sounds

You can adjust the sounds for Ringtone, New text message, New voicemail, New email and other options.

- 1 On Start screen, tap the arrow (➔) to go to your App list.
- 2 Tap **Settings > System > ringtones & sounds**.

Switch to the silent mode

You can switch to silent mode by pressing volume up or down, and tapping the bell icon.

Adjust the volume of the ringtones

Press the Volume key up or down to adjust the ringtone volume.

Select a wallpaper for the lock screen

- 1 On Start screen, tap the arrow (➔) to go to your App list.
- 2 Tap **Settings > System > lock & wallpaper > change wallpaper**.
- 3 Select an image and save.
You can also change the Screen time-out and set a password.

Adjust the brightness of the display

To adjust the brightness in the setting menu,

- 1 On Start screen, tap the arrow (➔) to go to your App list.
- 2 Tap **Settings > System > brightness**.
- 3 Drag the slider of **Automatically adjust** to Off and tap the desired brightness level.

NOTE: The brightness level of the display will affect how quickly the device consumes battery power.

Lock your SIM card

You can lock your device by activating the PIN supplied with your SIM card.

- 1 On Start screen, tap the arrow (➔) to go to your App list.
- 2 Tap **Settings** and drag to select **application > phone**.
- 3 Drag **SIM security** Slider to **On**.
- 4 Enter your PIN and select **enter**.

Navigating your Windows Phone

NOTES:


- Once the PIN lock is enabled, you must enter the PIN each time you turn on the device.
- If you enter an incorrect PIN too many times, your SIM card will be blocked. You must enter a PIN Unlock Key (PUK) to unblock the SIM card. If you enter the incorrect PUK too many times, your SIM will be permanently locked and require replacement.

Enter text

This section outlines how to select the desired text input mode when entering characters into your phone. This section also describes how to use the on-screen keyboard to ease the text entry method.


Here are some tips for using the on-screen keyboard and text suggestions.

Keyboard overview




1. shift and caps lock
2. number and symbols
3. emoticons
4. enter
5. delete

To find numbers and symbols





When you tap the Numbers and symbols key , you'll see: 0-9, common punctuation, common symbols.

Note: In Messaging, if you tap the Numbers key from the To: line, you'll get a dial pad so you can easily type a phone number.



To find more symbols

Tap **More**  from the numbers keyboard to show more symbols, including foreign currency symbols, mathematical symbols, and a few other useful ones.


To find still more symbols

Some of the symbol keys can bring up yet more symbols. Tap and hold to see more options. For example, if you tap and hold the left parentheses key , you'll see left angle bracket , left brace , and left square bracket , too.

To use emoticons (smiley faces)

When you're typing an email or SMS message, your keyboard offers two full pages of smiley (and frowny and kissy and silly) faces. Tap the Happy face  to see the first screen, then tap **More**  to see the rest.

To turn on Caps Lock

Tap and hold or double-tap the Shift key . Tap it again to turn it off.

To quickly add a period

Tap Space twice to add a period.

To add accents to letters

- Automatically: For many words, your phone will realize when a word requires an accent and add it for you.

- Tap and hold: Tap and hold any letter that can include an accent, and all of the possible accents for that letter appear. Tap the one you want to add.

To place your cursor where you want it

If you want to place your cursor in the middle of some text you've already written, tap and hold the screen near the text you want to change until a cursor appears, then drag your finger to move the cursor exactly where you want it.

If you want to select an entire word, tap the word.

To use text suggestions and automatic corrections

When you start typing, you'll notice that your phone suggests words based on the letters you've typed so far. You can tap the suggestion to add it to your message, or keep typing until you see the one you want. If a suggested word is bold, your phone will use it to replace the typed word automatically. It'll also automatically add apostrophes to contractions (for example, "don't" will be replaced with "don't") and accents where appropriate.

If it's not bold, you can tap the suggested word to replace the one you've typed. Flick left to see more options.

If you realize later that you mistyped something, it's not too late. Tap that word and your phone will bring back some suggestions for you.




To change the settings for text suggestions

You can choose whether to allow text suggestions, correct misspelled words, insert a space after selecting a suggestion, reset text suggestions, and more.

- 1 On Start, flick left to go to the Apps list.
- 2 Tap **Settings > Keyboard**.
- 3 Do one of the following:
 - Select or clear any of the check boxes for the settings you want to change.
 - To remove all the words you've added to your suggestion list, flick up and tap **Reset text suggestions**.

Download applications from Marketplace

Marketplace enables users to easily find & acquire music and applications (including games) to enhance their Windows Phone. Individual category pages have been added to the site for apps and games, and music.

- On Start screen, tap the arrow  to go to your App list and tap **Marketplace** . Or, tap **Marketplace** tile from the Start screen.
- Press the **Search** button to search for apps.
- Type in the desired string and tap  and the results will be displayed below on the same page.

Navigating your Windows Phone

- Tap an item in the list of search results to open that Marketplace item.
- While browsing or searching for an app, a user can tap on an application or game and the Details page for the app will appear.
- Select the item you want to buy and tap **install**.



NOTES:

- Pictures, podcasts, and videos are not available on the Marketplace.
- This feature may be unavailable depending on your region.

Getting Started

When you turn on your phone for the first time, you will be guided through essential settings. Please follow the instructions on the screen to activate your device.

Please note that during the "WINDOWS PHONE SETTINGS" step, **recommended** settings includes activating sending feedback to Microsoft. This feature will consume data and may incur data charges. To avoid this select custom and uncheck "Send information to help improve Windows Phones". If you want to disable this later, open the application list and select **settings > system > feedback** and turn off the **Send feedback** option.

CHOOSE A LANGUAGE > WINDOWS PHONE SETTINGS > CHOOSE TIME ZONE > Sign in with a Windows Live ID

Step 1. Sign in with a Windows Live ID



To download applications, play Xbox LIVE games, use a Zune Pass, synchronise Windows Live information to the web and more, you will need to sign in with a Windows LIVE ID. Please note that the Zune Pass is not available in all countries/regions.

A Windows Live ID is the email address you use to sign in to services like Xbox LIVE®, Zune®, Hotmail®, and so on. If you can't remember the email address you use:

For Xbox LIVE: On your Xbox 360® console, sign in with your gamer tag, then press the Guide button on your controller (the one in the middle that looks like the Xbox logo). In Settings, click **Account Management > email & accounts**.

For Zune: Install the Zune Software(dorado) in advance. Sign in to the Zune software on your PC. Right-click your profile picture and click Switch user to see your Windows Live ID. To reset your password or get a reminder, go to <http://account.live.com/ResetPassword.aspx>.

If you haven't yet signed in with a Windows Live ID, there are a few things you won't be able to do on your phone for the moment (for example, get applications or play Xbox LIVE games).

Getting Started

Step 2. Import your contacts




When you set up your email or Facebook account, your contacts are imported automatically into your People hub. And when you add Facebook, your friends' feeds appear in your People hub, their photos show up in your Pictures hub, and your own feeds pop up in your Me tile.

To set up a Facebook (or any kind of email) account:

- 1 Tap the arrow on Start to go to your App list.
- 2 Tap **Settings > System > email & accounts**.

Getting your contacts from your old phone is also easy. Put your old SIM card into your new phone, then go to Settings. Flick to applications, tap people, then tap import SIM contacts.

Step 3. Stay in Sync








To sync your music, videos, pictures, and updates from your computer to your phone (or vice versa), you'll need the Zune software.

- 1 Connect your phone to your computer using the cable.
- 2 Go to www.microsoft.com/windowsphone/en-ca/howto/wp7/start/install-the-zune-software.aspx to install the Zune software.
- 3 Open the Zune software, then follow the instructions to get your music, videos, pictures, and so on into your collection.
- 4 Click collection, then drag everything you want to sync to the phone icon in the lower left.

Communication

Phone


Making phone calls

- 1 Touch .
- 2 Tap .
- 3 Enter the number on the keypad.
To delete a digit, touch .
- 4 Touch  to make a call.
- 5 To end a call, touch .

You can also place calls using the Phone Tile on start.

TIP! To enter “+” to make international calls, touch and hold down [0+].

Calling your contacts

- 1 Touch People to open your contacts.
- 2 Scroll through the contact list or enter the first letter(s) of the contact you want to call by touching .
- 3 In the list, touch the contact you want to call, then select the number to use if there is more than one for that contact.

Answering and rejecting a call

When your phone rings, tap the **answer** button to accept the call. If your screen is locked you will need to flick up to unlock and access the **answer** button.

Tap **ignore** tab to reject an incoming call.

TIP! When the phone rings, press the volume down button on the right if you want to switch to silent ringer mode.

Airplane mode (to disable wireless communication)





Some locations may require you to turn off your phone’s wireless connections by placing your phone in Airplane mode.

Tap **SETTINGS > system > airplane mode**. This feature toggles your phone’s mobile, Wi-Fi, and Bluetooth radios simultaneously.

Adjusting call volume

To adjust the volume during a call, use volume up & down button on the right side of the phone.


Making a second call

- 1 During your initial call, Touch the  then tap .
- 2 Call the number, or search your contacts using the  or .
- 3 Touch the call icon to connect the call.
- 4 Both calls will be displayed on the call screen.
Your initial call will be locked and put on hold.
- 5 Touch PRESS TO SWAP on the top of the screen to toggle between calls.
- 6 To end active calls, touch **end call**.
If there is no active call, it will end the held call.

Communication


NOTE: You will be charged separately for each additional outbound call. I.e. if you have one outbound call active and one outbound call on hold, you will be charged for both the active call and the held call.

Viewing your call history

On the Start screen, press the  to view Call log.



View a complete list of all dialed, received, and missed voice calls.

TIP! Touch any single call log entry to view the date, and time of the call.

TIP! Tap the  button, then touch **delete all** to delete all the recorded items.

Call settings

You can configure phone call settings, such as call forwarding, and other special features offered by your carrier.

- 1 On the Start screen, touch .
- 2 Tap the  button at the bottom of the call history screen and open the **Call settings**.
- 3 Scroll and tap call settings. and choose options that you want to adjust.

Voicemail number - Edits the Voicemail number


Show my caller ID to - Choose whether to display your number on an outgoing call.

Call forwarding - It will help automatically correct some common mistakes while dialing internationally or dialing while abroad.

Searching for a contact


There are two ways to search for a contact:

On the Start screen

- 1 On the home screen, touch the **People** Hub Tile to open your contacts (People hub).
- 2 Touch  and enter the contact name using the keypad.





TIP! To search by contact first initial, tap any of the letters. e.g. tap the "a" shown above the contacts starting with "a" and a list of initials will be displayed to select.

From the application menu



- 1 On the Start screen, touch  to go to the application lists.
- 2 Touch the People and select the desired profile.

Messaging


To send a text message


- 1 On Start, tap **Messaging**  > **New** .
- 2 Do one of the following:
 - Begin typing a person's name in the To: box, and then tap a matching contact name in the list. Repeat to add more recipients, and their names will be added automatically in the To: box.
 - Enter the person's mobile phone number or their email address in the To: box. To enter additional recipients, tap Enter after each one.
 - Tap Add , flick to a contact, and then tap it. Repeat to add more recipients, and their names will be added automatically in the To: box.
- 1 Tap the message box, type your message, and then tap **Send** .


To reply to a text message

- 1 On Start, tap **Messaging** , and then tap the conversation that has the text message you received.
- 2 Tap the message box, type your response, and then tap **Send** .

To forward a text message

- 1 On Start, tap **Messaging** , and then tap the conversation that has the text message you want to forward.
- 2 Touch and hold a message, and then tap **Forward**.


- 3 Type the person's name, mobile phone number, or email address in the To: box.
- 4 Tap the message box, type a message if you'd like, and then tap **Send** .



NOTES:

- Text messages are also called SMS (Short Message Service) messages and can be up to 160 characters long.
- If your text message is longer than 160 characters, it will be sent in one or more additional messages.
- Sometimes mobile operators will send a text message that you can't reply to or forward, and the message box says Read-only message.

Save a picture from a text message

- 1 On Start, tap **Messaging** .
- 2 Tap a conversation that has a picture, and then tap the picture.
- 3 Touch and hold the opened picture, and then tap Save to phone. The picture is saved in the Saved Pictures album on your phone.

Communication

NOTES:

- Your mobile operator might charge you extra for picture messaging, and this service must be available with your current phone plan.
- Text messages that have a picture attached are also called MMS (Multimedia Message Service) messages.
- Some pictures you receive might be protected using digital rights management and can't be saved to your phone.

Email

Setting up an email account


Whether it's personal or work-related email, you can get to it from your Windows Phone by setting up different types of email accounts. Depending on the email account you set up on your phone, other items from your account (such as contacts, calendar, and more) can appear on your phone as well.

NOTE: To set up an email account on your phone, you must have a working mobile data or Wi-Fi connection. For more information about connecting to a Wi-Fi network, see [Connect to a Wi-Fi network](#).

Setting up a Windows Live account

When you're first setting up your phone, you're asked to sign in with your Windows Live ID. If you didn't sign in with it at that time or if you have more than one Windows Live ID, you can use the steps below to set up your primary Windows Live ID or

additional Windows Live IDs.

On the Start screen, flick left to the Apps list, tap  **Settings**, and then tap **Email & accounts**.


- 1 Tap **Add an account > Windows Live** and follow the instruction on the screen.

NOTES:

- The first Windows Live account that you set up can't be deleted from your phone.
- If you set up additional Windows Live IDs on your phone, photos in those additional accounts won't be synced to your phone.
- You can create a Hotmail account here and retrieve new email messages from Hotmail to your Inbox. When you access this Hotmail application, the total number of new emails displays on the email tile.


Setting up a Microsoft Exchange email account

You can use the following steps to set up an email account that is on a Microsoft Exchange Server. (For example, your email account at work might be on a Microsoft Exchange Server.) You can also use the steps in the following procedure to set up other email accounts that use Exchange ActiveSync—including a hosted Microsoft Exchange email account or an Outlook Web App account.

- 1 On the Start screen, flick left to the Apps list, tap  **Settings**, and then tap **Email & accounts**.
- 2 Tap **Add an account > Outlook**.

Setting up an email account from an Internet Service Provider (ISP)

When you set up an email account, your phone will try to automatically find correct settings for your email account. The email account might be one that's through your Internet Service Provider (ISP), or it might be another IMAP or POP email account from another provider.

1 On the Start screen, flick left to the Apps list, tap  **Settings**, and then tap **Email & accounts**.

2 Tap **Add an account > Other account**.

The following is a list of settings that you'll need to know beforehand when the correct email account settings can't be found automatically. Generally, you can find this information on the provider's website.

- The email account type (POP or IMAP)
- The incoming email server address
- The outgoing (SMTP) email server address
- Server authentication settings
- SSL requirements for incoming email
- SSL requirements for outgoing email


Sending an email message

After you set up an email account on your phone, you can send or delete emails from that account.

1 On the Start screen, tap the email account that you want to access (for example, Outlook, Google, or Windows Live).

2 Tap **New** .


3 Do one of the following:

• In the To: text box, tap **Add** , and then choose a contact.

• Tap in the To: text box, and then start typing an email address. Your phone will offer suggestions as you type.

• To remove a recipient, tap their name or email address, and then tap Remove.

1 Tap in the Subject: text box and type a subject.

2 Tap below the Subject: text box, type your email, and then tap **Send** .

NOTE: You can attach files stored on your phone (such as pictures and documents) to an email before sending it.



Viewing email messages

1 On the Start screen, tap the email account that you want to access (for example, Outlook, Google, or Windows Live).

2 Select an email message.

Communication


From the message view, use the following options:

- To reply to or forward an email, tap **Respond** , and do one of the following:
- To delete one email, tap on the email to open it, and then tap **Delete** .
- To delete multiple emails, tap on the far left of an email you want to delete. A check box will appear. Tap the check box next to each email you want to delete, and then tap **Delete**.

Retrieving your email


You can automatically or manually check your account for new email.

To check manually:

- 1 Tap  on the Start screen to go to your App list and tap **Email** application. Or, you can also tap the Email tile on Start screen, and which is the account you want to use, like Hotmail, gmail, and so on.
- 2 Choose synchronise and your Windows phone will then connect to your email account and retrieve your new messages.

Changing your email account's settings

You can set up additional accounts based on your own preferences.

- 1 Tap  on the Start screen to go to your App list and tap **Email** application. Or, you can also tap the Email tile on Start screen.
- 2 Touch the Application bar at the bottom of the screen to open the options menu, and tap add email account.
- 3 Choose the email you want to change to . There are options such as Windows Live, Outlook, Yahoo! Mail, Google and other account.
- 4 Enter your email address and password, then it will automatically synchronise with your new email account.


You can change settings based on your own preferences.

- 1 Touch the Application bar at the bottom of the screen to open the options menu, and tap settings.
- 2 You can change detail sync options by tapping "sync settings" or checking/ dischecking "Always bcc myself" and "Use an email signature".

NOTES:

- In "sync settings" you can change the settings below download new content : the period of retrieving contents download email from content to sync(email, contacts, calendar) : enable/disable the contents and other detailed account information.

Deleting your email account

- 1 Tap  on the Start screen to go to your App list.
- 2 Tap Settings and go to email & accounts.
- 3 Touch and hold the account you want to delete and tap delete.

Facebook

Set up a Facebook account

When you set up your Facebook account on your phone, Facebook info is available throughout your phone. You can then access Facebook info in the People hub, Pictures hub, and the Me card.

- 1 On Start, flick left to the Apps list, tap **Settings > System > Email & accounts > add an account > Facebook.**
- 2 Tap **Add an account > Facebook.**

NOTES:



- To set up your Facebook account on your phone, you must have a working mobile data or Wi-Fi connection.
- You can only have one Facebook account set up on your phone at a time. At the same time you can log in to other accounts such as Windows Live, Facebook or Gmail.


Entertainment


Camera

Before using the camera, you will be asked whether you want to allow the camera to use your location. Allowing this option will add location info to your pictures so you can see where your pictures were taken.

To take a picture

- 1 On Start, flick left to the Apps list.
- 2 Tap the **Camera** icon.
Or press and hold the Camera hardware button  to start the camera.
- 3 Press and hold the Camera button  to start the camera.
- 4 Make sure the camera mode  is selected.
Hold the phone steady, either vertically or horizontally. You can zoom in or out  to get closer or further away from your subject.

TIP! Want to play with camera settings? Tap  to adjust various settings, including flash.

- 5 Press the Camera hardware button  to take a picture.
- 6 The picture is automatically saved in the **Camera Roll** album on your phone.
You can also choose to upload pictures to the web, including automatically sharing your pictures to SkyDrive or Facebook.



Once you've taken the photo

- 1 After you take a picture, flick right to see it in the picture viewer.

TIP! Want to see your pictures and videos in filmstrip view? Go to the camera, tap a picture or video, pinch it as if to shrink it, and then flick left or right to see the filmstrip. The filmstrip works best when you turn your phone sideways and view your pictures in landscape view.

- 2 Touch and hold the picture to view picture options such as adding it as a favorite, deleting it, using it as wallpaper, or uploading it to **Messaging** or **Play To**.

To record a video

- 1 On Start, flick left to the Apps list.
- 2 Tap the **Camera** icon
- 3 Press and hold the Camera button to start the camera.
- 4 Make sure the video mode  is selected.
Hold the phone steady, either vertically or horizontally.
- 5 Press the Camera hardware button  to start or stop recording.
The video is automatically saved in the Camera Roll album on your phone.

After shooting a video

- 1 After you record a video, flick right, then tap it to play it in the video viewer.

A still image representing your video will appear on the screen and the duration will be shown on the bottom of the screen.

NOTE: You can record and play HD video (1280x720 high-def resolution). If you connect your phone to your computer and copy the video to it, you can play HD video in its full 1280x720 resolution.

TIPS!

- If you want to watch videos on your phone that you downloaded from a website, connect your phone to the PC and sync them to your phone. You can't automatically upload videos to your phone.
- To find a video you captured from your phone that you synced to your computer, open the Zune software, click **Collection > Videos**.
- If you have a lot of pictures or videos that you want to delete, or if you want to save them to your computer, you can save time by connecting the phone to your computer and using the Zune software to do the heavy lifting for you.

Add location info to my pictures

When you include location (GPS) information in the pictures you take, the information can be seen by others after you upload and share them. Once you do, you and your friends can have fun viewing these pictures on a map using Bing and Windows Live Photo Gallery, and even searching the web for other pictures just like it because the location is embedded in your picture behind the scenes.

- 1 On Start, flick left to the Apps list, and tap **Settings > Applications > Pictures + Camera**.
- 2 Turn on Include location (GPS) info in pictures you take.

NOTE: If you want this information to stay with your pictures when you upload them to Facebook or SkyDrive, turn on Keep location info on upload pictures.

Getting to know the Camera mode


Camera/Video Record mode - Tap this icon to switch to Camera/Video Record mode

Zoom - Zoom in or zoom out.

Settings - Touch this icon to open the settings menu. See Using the advanced settings. Allows you to set up Intelligent Shot, Panorma shot, ScanSearch, Photo Resolution and so on.

Entertainment

Using the advanced Camera settings

From the viewfinder, touch  to open all advanced settings options.

After selecting the appropriate option, tap and set the related setting.

Setting Options	Function
Intelligent Shot	Your new Windows Phone automatically sets the shutter speed and aperture according to the subject and brightness for optimum recording.
Beauty shot	Your new Windows Phone automatically sets the focus and color balance to express the natural skin tone.
Photo resolution	The more pixels, the larger the file, which means the files take up more memory space. If you want to store more pictures on your phone, you can alter the number of megapixels to make the files smaller.
Brightness	Brightness enables you to set the recording brightness according to the condition.
White Balance	It automatically adjusts the color of the subject. You can record in natural colors depend on the subject and lighting conditions.
Color effect	Select the desired setting options on the menu: off, sepia, mono, negative, solarize TIP! You can change a picture taken in colour to black and white or sepia after it was taken, but you cannot change a picture taken in mono or sepia back to colour.
Quality	Choose between Super fine, Fine and Normal . The finer the quality, the sharper the photo. However, the file size will increase as a result, which means you'll be able to store fewer photos in the phone's memory.
Anti-shake	Reduce blur caused by the device's vibration or movement.

Setting Options	Function
Flash	Using the Flash function, you can set the built-in flash to fire under low light condition.
Video Resolution	The more pixels, the larger the file size, which means the files take up more memory space. If you want to store more videos on your phone, you can alter their resolution to make the files smaller.
Restore to default	Reset menus and shooting options.

Notes: Before taking a photo, you can go and tap **Setting > Application > pictures + camera** to access the following settings: GPS, SkyDrive.

The camera setting menus are various according to the user's application settings. For examples, if you download the ScanSearch application on your Windows Phone, ScanSearch menu will be displayed on the camera setting menu.

Entertainment

Pictures

Learn to view photos and play videos saved in your device's memory.

Pictures hub

The Pictures hub is Windows Phone's digital version of your printed pictures. Show off all the pictures you took with the built-in camera, saved from an email, text message, or off of the web, or downloaded from your PC.



- **Times Square wall.** A showcase of all your local pictures. The mosaic of picture-perfect moments changes every 5th time you turn on your phone. If you sync your phone using the Zune software before you visit the Pictures hub, you'll see your pictures here when you arrive.
- **What's New.** These are the latest pictures your friends and family uploaded to Windows Live or Facebook.
- **Picture collection.** You can view your pictures and videos by album, date, or favorites. When you add a picture as a favorite as part of your Favorites album, you can then pin that album to Start.
- **Hub background.** Tap anywhere in the hub to change the background or let us do it for you using any of your pictures. Either way, changing the background will also change the Pictures tile on Start.
- **Zune software.** Sync files with my phone to move pictures from your PC into albums on your phone and vice versa.

NOTE: When you go to the Pictures hub for the first time, you'll see 8 pictures from the 7 folder in the Times Square wall. To see a mosaic of your own pictures here, you need to tap and hold the 7 folder to delete it. The Times Square wall will now randomly pull in pictures from your Camera Roll as well as albums you sync from your PC or your social networking sites.

- Some file formats are not supported depending on the software of the phone.
- If the file size exceeds the available memory, an error can occur when you open files.

Picture Albums

Picture albums are a big part of how you organize your pictures and videos—on your phone, on your computer, and on the web. Knowing where albums can be added to and deleted from will help keep everything in working order.

The Zune software puts pictures from your phone albums—Camera Roll, Saved Pictures, Received Pictures—into the Pictures library on your computer.

NOTE: With the exception of viewing and deleting albums, all other album tasks must be completed using the Zune software on your computer.

To view albums

- 1 Do one of the following:
 - On your computer, click **Phone > Pictures**.
 - On your phone, in the Pictures gallery, tap **All**.
 - On your phone, in the Pictures hub, flick to **What's new**.

Viewing a picture

- 1 On Start screen, tap the arrow to go to your App list and tap **Pictures**. Or, tap **Pictures** tile from the Start screen if it's pinned as your favorite Tile on Start.

- 2 In Pictures, pan and go to picture albums (all, date, favorite) and tap a photo tile to open and view.

While viewing a photo, use the following options:

- To view more photos, scroll left or right.
- To zoom in or out, You can tap the screen with two fingers and spread them apart (move your fingers closer together to zoom out).

Playing a video

- 1 In Pictures, pan and go to picture albums (all, date, favorite) and tap a video tile to open and view.
- 2 Tap a video tile to view.
- 3 Rotate the device anti-clockwise to landscape view.
- 4 Control playback with the virtual keys.


NOTE: Only recorded videos with your Windows Phone can be played.

Share pictures

- 1 On Start, tap **Pictures**.
- 2 Find a picture you want to share. Pictures from online albums can't be uploaded.
- 3 Touch and hold the picture, then tap **Share**.
- 4 Choose **Messaging** or **upload to Play To** to share or upload your picture to the web-text or email message or sharing.

Entertainment

NOTE: SkyDrive is part of Windows Live, a password-protected service on the web (photos.live.com), where you can store and share your documents and pictures up to 25 GB for free. Sign in with your Windows Live ID and you're all set.

TIP! After you upload your pictures to SkyDrive from your phone, you can find and edit them within Windows Live Photo Gallery on your computer without having to connect to the web. You must have a computer running Windows Vista or Windows 7. To see if you have Windows Live Photo Gallery installed, from your computer, click the Start button . In the search box, type photo gallery, and in the list of results, click Windows Live Photo Gallery.

Favorites in the Pictures gallery

Using the Favorites album on your Pictures hub has the advantage of putting your most interesting pictures in one place for easy viewing. Pictures in Favorites are also the only ones you can pin to Start (if you have certain pictures that make you happy every time you see them).

- 1 On Start, tap **Pictures** and find a picture and tap to open it.
- 2 In the picture viewer, touch and hold the picture, and then tap **Add to Favorites**.

TIP! Want to add a picture from an online album as a favorite? Open a picture, tap it, then tap Save to phone. The picture will be added to the Saved Pictures folder (In the Pictures hub, go to All > Saved Pictures). Find the picture, then follow Step 3 above to add a saved picture as a favorite.

Add or delete a caption from a picture

To add a caption

You can add captions to pictures that you upload to Facebook or Windows Live.

- 1 Tap the picture, and then tap **Share**.
- 2 Choose an account to upload your picture.
- 3 Tap the text box to type a caption.
You have 4 seconds to start typing or the picture will be uploaded without a caption.

4 Tap **Upload**.

To delete a caption

You must be on your computer to delete a caption, and you can only delete a caption from a picture that you've uploaded.

- 1 Find your picture.
- 2 Sign in and follow the steps provided by Facebook or Windows Live to delete a caption.

Add location info to my pictures

When you include location (GPS) information in the pictures you take, the information can be seen by others after you upload and share them. Once you do, you and your friends can have fun viewing these pictures on a map using Bing and Windows Live Photo Gallery, and even searching the web for other pictures just like it because the location is embedded in your picture behind the scenes.

- 1 On Start, flick left to the Apps list, and tap **Settings > Applications > Pictures + Camera**.
- 2 Turn on Include location (GPS) info in pictures you take.

NOTE: If you want this information to stay with your pictures when you upload them to Facebook or SkyDrive, turn on Keep location info on upload pictures.

Music & Videos

Zune software. Sync files with my phone to move musics and videos from your PC into albums on your phone and vice versa.

Get music, videos, and podcasts from Marketplace

Zune Marketplace is your one-stop shop for great music, podcasts, movies, videos, TV shows, and more. Some stuff is free to play, download, or sample, where other items are available to buy or rent.

There are two ways to access Zune Marketplace:

To download or stream music directly to your phone

- 1 On Start, tap **Music & Videos**.
- 2 Flick to Zune, and then tap **Marketplace**.
- 3 Find a song, album, artist, or playlist by doing one of the following:
 - Flick left or right, browse through the available categories, and then tap the desired item.
 - Press the Search button , enter a song title, album title, or artist name, and then tap the desired item.
- 1 Follow the instructions to get your music, videos, pictures, and so on into your collection.

To sync music, videos, pictures, and podcasts to your phone

There are several ways to copy or sync files to and from your phone. To sync multimedia files between your phone and your PC, you must install a free program called Zune software on your computer. The Zune software helps you organize your multimedia collection, choose what to sync

Entertainment

to your phone, and even download new stuff from Zune Marketplace.

- 1 Connect your phone to your PC using the USB cable that came with your phone.

If the Zune software is installed on your computer, the program will start automatically. If it isn't installed on your computer, please install the Zune software. If this is the first time you've connected your phone to your PC, follow the instructions in the Zune software to name your phone and perform other setup tasks.

- 2 In the Zune software, click **Collection**.
- 3 Find the item you want to sync by doing one of the following:
Click a category (Music, Videos, Pictures, or Podcasts), and browse until you find the item you want to sync to your phone (such as a song, album, artist, playlist, genre, and so on).
In the Search box, enter what you're looking for (for example, a song title or artist name). In the search results, click the desired item.
- 4 Drag the item to the phone icon in the lower-left corner of the Zune software.

NOTE: Not all items are available for purchase, rental, download, or streaming. Zune Marketplace is not available in all locations or languages. Zune Marketplace content varies by market. To learn more about using Zune Marketplace, go to **Zune.net**.

Play music, videos, and podcasts

Your Windows Phone isn't just a phone. It's also a great Zune music and video player.

Listen to music while you surf the web or check your email, catch up on your favorite podcasts on your commute, or enjoy a movie on your next flight. There's no need carry another device with you. Windows Phone has all your entertainment needs covered.

To play music, videos, and podcasts

- 1 On Start, tap **Music & Videos**.
- 2 Flick to **Zune**, and then tap **Music, Videos, or Podcasts**.
- 3 Find the item you want to play by doing one of the following:
 - Flick left or right, tap a category (such as Artists, Albums, or Songs), and flick up or down as necessary.
 - To search Zune Marketplace, press the Search button, and then enter a song title, album title, or artist name. (Zune Marketplace may not be available in some countries or regions.)

- 1 Tap the item that you want to play. If you need to adjust the volume, press the Volume Up or Volume Down buttons on the side of your phone.

Type	Format	Sync from Zune SW
Audio	Extension: mp3, mp4, m4a, wma Codec: MP3, AAC, WMA	Extension: mp3, mp4, m4a, wma Codec: MP3, AAC, WMA
Video	Extension: 3gp, 3g2, mp4, m4v, wmv Codec: MPEG4, H263, H264, VC-1	Extension: mp4, m4v, wmv Codec: MPEG4, H.264, VC-1

TIPS!

- There's a quick way to play all your music in random order. Flick to Zune, and then tap Play . This icon is next to Music.
- If you have a lot of items in a category (such as Songs or Albums), there's a quick way to jump to a particular point in the list without a lot of scrolling. For example, let's say you're at the top of the Songs list (in the "a" section) and you want to play a song that starts with the letter "s." Tap the colored box with the letter "a" in it. In the grid of letters that appears, tap S

TIPS!

- When playing songs or audio podcasts, you can also skip to the next and previous items in the playlist by flicking right or left.
- When playing videos, tap the screen to display the playback controls. Press the Back button to return to Music & Videos.
- Press the Volume Up or Volume Down buttons to show the mini playback controls. This works even when the screen is locked.

To show the current playlist

When you're playing music, the next few items in the playlist are displayed beneath the album image. To see all items in the playlist, do the following:

- 1 Tap the name of the current song (beneath the album image).
- 2 To hide the playlist, wait a few seconds or press the **Back**  button.

TIP! To play a different song in the playlist, flick up or down as necessary, and then tap the name of the item you want to play.

Entertainment

To show what's playing now

1 Do one of the following:

- Press the Volume Up or Volume Down buttons. The name of the current song is shown above the mini playback controls. This works even if your phone is locked.
- In Music & Videos, flick to History.

To show related info about a song

- 1 In **Music & Videos**, when playing a song, tap the artist name.
- 2 Flick left or right to see information (when available), such as other albums by this artist, album reviews, and artist biographies.

Games

Games hub

From the Games hub, you can play games not just on the phone, you can also connect to and extend your gaming experience to your computer and your Xbox console.

- **Spotlight.** Read up on Xbox LIVE game news, tips, and trends from the Xbox LIVE team.
- **Xbox LIVE Gamer Profile.** Look at your profile to view recently played games, see your gamercard, change account information, and even personalize your avatar.

- **Requests.** View invitations to quickly jump into game play, keep up with turn notifications in a turn-based game, or accept a nudge from your buddy to make the next move.
- **Collection.** View all Xbox LIVE and other games that you have on your phone in one place.

To play a game

Xbox LIVE might not be available in your area. If it is available and you want to play games, use an existing Xbox LIVE account or set up an Xbox LIVE account. You'll need to install the game on your phone before you can play it.


- 1 On Start, tap **Games**.
- 2 Tap to open a game you've already purchased.
If you want to play an Xbox LIVE game, you'll need to sign in to (or join) Xbox LIVE.
- 3 If you want to see whether you have a game invitation or a turn notification, flick left to Requests.
If you want to play a game with a friend, but don't have any games on your phone that allow more than one player, flick to the bottom of your collection, then tap Get more games to see what you can try or buy from Marketplace.

NOTE: Xbox LIVE may not be available in your country or region.



FM Radio

Learn to listen to music and news on the FM radio. To listen to the FM radio, you must connect the supplied headset, which serves as the radio antenna.

To listen to a station

- 1 Plug the supplied headset into the device. The headset is used by the FM Radio as the antenna.
- 2 On Start, tap **Music & Videos**.
- 3 Flick to **Zune**, and then tap **Radio**.
- 4 To choose a station, do one of the following:
 - Swipe left or right to go up or down the dial. (If you flick instead of swipe, the radio will auto-tune to the next station.
 - Tap **Favorites**  to show your favorite stations.



TIPS!

- Tap Play  or Pause  to start or stop playback.
- When the screen is locked, press the Volume Up or Volume Down buttons to show the mini playback controls. You can use the controls to pause or resume the radio or to skip to the next or previous station.

NOTE: As you switch channels, you might see info about each station, such as its genre and what song or program is currently playing. It's up to each station to choose what they broadcast, so you might not see info for every station.

To add or remove a favorite station

To tune into stations more quickly, try adding a few as favorites.

- 1 Tune in to a station.
- 2 Do one of the following:
 - To add the station as a favorite, tap **Add Favorite** .
 - To remove the station as a favorite, tap **Remove Favorite** .

TIPS! To show your favorite stations, tap Favorites . You can also pin your favorite station to Start by pressing and holding the station number.

Entertainment

To switch between speaker and headset modes

- 1 While playing a station, touch and hold the station number.
- 2 Tap **Radio mode**: headset or Radio mode: speaker to switch between the two options.

To switch radio regions

If you travel internationally, you might need to switch the radio region setting to listen to FM radio when you're abroad. If you do change this setting, don't forget to switch it back to the original setting when you get home.

- 1 While playing a station, touch and hold the station number.
- 2 Tap **Settings**.
- 3 On the Radio screen, tap the Region box, and then tap the name that corresponds to your desired radio region.

Personal Information

People Hub

The first time you start up Windows Phone 7, the **Start** screen will be fairly bare. In the People Hub, in particular, most of the nine squares in the hub will be empty. After you import your contacts, you can add photos to your contacts, and the People tile squares will show small thumbnails of your contacts. For first time use, tap the **People Hub** to go to it.

Accessing the People Hub

When you open a contact, you'll have all the information you need to connect with your friend in just a few taps.

Tap the method you want to use to connect with your contact. It could be by phone, text messaging, email, or Facebook.

For first time use, tap the People hub.

Later, when you have set up contacts and photos, you'll be able to click each of the smaller nine tiles in the People hub to go directly to a contact or to Facebook.

About the contacts

Each contact has the name of the person at the top of the screen. Underneath are the ways to reach him (text mobile, call home, send email, etc.), as well as any personal information you want to enter.

Importing contacts



One of the first things you'll do with your new phone is to create contacts. You start by importing your existing contacts. Contacts can be imported by your SIM card

and through email. They are automatically brought into the People Hub.

- 1 On Start screen, tap the arrow to go to your App list and tap **Settings > applications > people**.
- 2 Tap **import SIM contacts** to start the process.
You can also import contacts from your email accounts. Your MSN, Hotmail, and Live.com accounts are all part of Windows Live services and easily downloaded to your phone.
Tap Windows Live to import your contacts and calendar info from these accounts.

Adding a new contact

Now, let's add a contact manually.

- 1 On Start, go and tap People, and tap the **plus icon**  on the **People Hub**.
- 2 To add information, tap the plus sign icon for each field you want to work with.
- 3 Tap the text field. Add the information using the virtual keypad.
- 4 Type and add the information using the keypad.
- 5 Tap the **Done icon**  at the bottom of the screen when you're done with that field.


To link a person's contact to another:

- Tap the link icon (circled chain link) at the bottom of the screen and choose a contact.

Personal Information

To edit a contact

You can add or change information for a contact, then choose which account you want to store the changes in.

- Flick to **All**, find and tap the contact you want to edit, and then tap **Edit** .

To delete a contact


While you can't delete a Facebook contact on your phone, you can delete contacts from other services. When you do this, the contact will be deleted both from your phone and from the online service where it is stored.

Find a contact

Contacts on your phone can come from Facebook, services like Windows Live or Google, email accounts, or ones you've created from scratch. If you find that your contacts list is getting rather long, don't fret—here are some tips to make life a little easier.

To jump to a letter of the alphabet

You can jump to a letter of the alphabet rather than scroll through your entire contacts list.

- 1 On Start, tap **People** .
- 2 Flick to **All**, tap any letter of the alphabet, and then tap the desired letter to jump to that point in your contacts list.

To search your contacts list

If your contacts list is especially long, search is probably the best way to find something.

- 1 On Start, tap **People** .
- 2 Tap **Search** , and then start typing someone's name.
The list will filter as you type.


Pin a contact

When you pin a contact to Start, you'll get all of that person's feed updates right from that tile, and it's like speed dial: it takes only two taps to make a phone call.

- 1 On Start, tap **People**, then flick to **All**.
- 2 Do one of the following:
 - Tap and hold the contact you want to pin, then tap Pin to Start.
 - Tap the contact you want to pin, then tap Pin.

Me card

The Me card is your profile on your phone. It's also where you go to see your most recent Facebook and Windows Live posts, and to post something new.

- On Start, tap **People** , flick to **All** and then tap your profile picture.
- Or On Start, tap **Me**.

Here are some things you can do on the Me card:

- Post a new message to Facebook or Windows Live.

- Update your profile picture on your social networks. You can update your profile picture on your phone, Windows Live, and Facebook all at once.

Post to Facebook and Windows Live




You can post messages and pictures to Facebook and Windows Live from your phone, or comment on other people's posts. When you write a new message, you can choose whether you want to post it to Facebook, Windows Live, or both.

- 1 On Start, tap **Me**, and then tap your most recent message (to the right of your profile picture).
- 2 Type the message you want to post. If you have more than one social network account set up on your phone, tap the check box next to each account to choose which ones you want to post to.
- 3 Tap **Post** .

Calendar

Learn to create and manage daily, weekly or monthly events, and set alarms to remind yourself of important events.

Create an event


- 1 On Start screen, tap the arrow to go to your App list and tap **Calendar** .
- 2 Tap month  to select the desired **date** > **new** icon .
- 3 Enter the details of the event as required and tap save icon.

View events

To change the calendar view,

- 1 On Start screen, tap the arrow to go to your App list and tap **Calendar** .
- 2 Simply swipe your finger left/right to view the today's event as agenda or day view.

To view events of a specific date,

- 1 On Start screen, tap the arrow to go to your App list and tap **Calendar** .
- 2 Tap the **month** icon to select a date on the calendar.
- 3 Tap an event to view its details.

Office

Get started with Microsoft Office Mobile

Microsoft Office Mobile 2010 includes mobile versions of Microsoft Office applications that are made for your Windows Phone 7. You don't need to download or install anything else either. Just go to the Office hub on your phone to open and work on your Microsoft Office documents.

- Office Mobile 2010 starts in the Office hub

Personal Information

The Office hub is the place to get started with Office Mobile 2010. Through the Office hub, you can start using the different Office Mobile applications on your phone—including:

- Microsoft Word Mobile 2010
- Microsoft Excel Mobile 2010
- Microsoft PowerPoint Mobile 2010
- Microsoft OneNote Mobile 2010
- Microsoft SharePoint Workspace Mobile 2010



To get to the Office hub, on Start, flick left to go to the Apps list, and then tap **Office**. (If you think you'll use Office Mobile 2010 a lot, pin it to Start.)

Use Microsoft Word Mobile






With Microsoft Word Mobile 2010, you can create new Microsoft Word documents or read and revise existing ones on your phone. Because it's part of Office Mobile 2010 and already on your Windows Phone 7 in the Office hub, you don't need to download anything else to get started.

Note: Word Mobile doesn't support all the features that are found in Microsoft Word 2010. If a document has content that's not supported in Word Mobile, you can still open the document on your phone, but the unsupported content won't be displayed.

To create a new document

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to Documents, tap **New document**  > **Word document**.

To edit a document

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **Documents**, and then tap the Word document you'd like to edit.
- 3 Tap **Edit** .
- 4 To format the text, tap **Format** , and then do one or more of the following:
- 5 Type text you want to add.
- 6 To stop formatting the text, tap Format , and then tap an icon for the formatting that's currently being used to turn it off.
 - **Remove Favorite** .

TIPS!



- You can use more than one formatting option at a time. To do this, tap Format, and then choose the first formatting option. After that, tap Format again and choose the next formatting option you want to use, and then type your text.
- You can also format text by selecting it first, and then applying the formatting that you want to use.

Use Microsoft Excel Mobile

Microsoft Excel Mobile 2010 allows you to create or edit Microsoft Excel workbooks right on your phone. Because it's part of Microsoft Office Mobile 2010 and already on your Windows Phone 7, you don't need to download or install anything else to get started.

Note: Excel Mobile doesn't support all the features and functions that are found in Microsoft Excel 2010. If a workbook has content that's not supported, you can still open the workbook on your phone, but the unsupported content won't be displayed. If a function isn't supported, the calculated value still appears in the cell but won't be recalculated if the data changes. Some data and formatting might be lost when you save it on your phone.

To create a new Excel workbook

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **Documents**, tap **New document**  > **Excel workbook**.


Use Microsoft PowerPoint Mobile

With Microsoft PowerPoint Mobile 2010, you can open and view Microsoft PowerPoint presentations, make small changes, and add notes if you want. You can even watch a presentation that's broadcast online. Because PowerPoint Mobile is part of Office Mobile 2010 and already on your Windows Phone 7 in the Office hub, you don't need to download or

install anything else to get started.

Note: PowerPoint Mobile doesn't support all the features that are found in Microsoft PowerPoint 2010. If a presentation has content that's not supported, you can still open the presentation on your phone, but the unsupported content won't be displayed or will be displayed differently.

To open an existing PowerPoint presentation

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **Documents**, and then tap a PowerPoint presentation.

Use Microsoft OneNote Mobile

Microsoft OneNote Mobile 2010 lets you take new notes and view existing Microsoft OneNote notebooks on your Windows Phone 7. You can use your notes as an extension of your mental memory, helping you remember everything from what happened in that meeting at work to what you need to pick up at the grocery store on the way home. Because OneNote Mobile is part of Microsoft Office Mobile 2010 and already on your Windows Phone 7 in the Office hub, you don't need to download or install anything else to get started.





In addition to storing notes on your phone, you can also add notes to a OneNote notebook that's created for you and synced to Windows Live SkyDrive. This way, you can view and edit your notes on your phone using OneNote Mobile, on your

Personal Information

computer using Microsoft OneNote 2010, or online using Microsoft OneNote Web App in a web browser.

Note: OneNote Mobile doesn't support all the features that are found in Microsoft OneNote 2010 or Microsoft OneNote Web App. If a notebook has content that's not supported in OneNote Mobile, you can still open the notebook and view it on your phone, but the unsupported content won't be displayed in OneNote Mobile.




To create a new note in OneNote Mobile

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **OneNote**, and then tap New note .
- 3 If you want to include a title, tap Enter title, and then type a title.
- 4 Tap below the title, and then type your notes.
- 5 To undo the last change you made, tap **More**  > **Undo**.
- 6 To redo the last change you undid, tap **More**  > **Redo**.

Notes

- These notes are stored on your phone. Like Microsoft OneNote on your computer, your changes are saved automatically when you leave OneNote Mobile, such as when you press the Back or Start button on your phone.
- If you don't type a title, the first line of text in your note will be used as the title.

To sync a notebook on Windows Live SkyDrive for the first time

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **OneNote**, and then tap **All** .
- 3 Tap **Refresh** .
- 4 Tap **Yes** in the Sync with SkyDrive message box.
Wait while you're signed in with your Windows Live ID.
Afterwards, a personal notebook named Personal (Web) will be created in your My Documents folder on Windows Live SkyDrive and synced on your phone.
- 5 Type your notes.

Notes

- To ensure that this notebook syncs properly to Windows Live SkyDrive, do not change the default notebook name from Personal (Web), and don't change the name of the Unfiled Notes section in the notebook.
- Before you can create and sync your default OneNote notebook, a Windows Live ID must be set up on your phone, and you must accept the End User License Agreement for Windows Live SkyDrive.

Use Microsoft SharePoint Workspace Mobile


With Microsoft SharePoint Workspace Mobile 2010, you can open, edit, and save Microsoft Office documents that are on a SharePoint 2010 site (a website that lets you and others share and collaborate on documents, projects, schedules, and ideas).

You don't need to download or install anything to start using SharePoint and Microsoft Office documents on your phone. SharePoint Workspace Mobile is part of Microsoft Office Mobile 2010 and is already there in the Office hub on your phone.

Notes

- To access a SharePoint site using SharePoint Workspace Mobile from inside your organization, you'll need to set up a Wi-Fi connection that lets you access a SharePoint site on your company's network.
- If you'd like to learn more about SharePoint, visit the Microsoft SharePoint 2010 website.




To open a SharePoint site for the first time using SharePoint Workspace Mobile

- 1 On Start, flick left to the Apps list, and then tap **Office** .
- 2 Flick to **SharePoint**, and then tap **Open URL** .
- 3 Next to http://, type the address for a SharePoint site, document library, list, or folder, and then tap Go . If you're at your computer, it might help to open the SharePoint site on it, so you can see the SharePoint address that you'll need to type on your phone.
- 4 If the Signing in screen displays, do the following, and then tap **Done**:
If you have an Exchange email account set up on your phone, SharePoint will try to use that user name and password information to sign in to the SharePoint site. If it's successful, you won't need to enter your user name and

password and this screen won't appear.

- 5 Tap **More**  > **Bookmark this link** > **OK** in the Link added screen to bookmark the link for later.

To browse a SharePoint site


- 1 After you've opened a SharePoint site in SharePoint Workspace Mobile, go to **SharePoint** in the Office hub, and then tap **All** .
- 2 At the top, tap **Links**, and then tap the SharePoint site, document library, list, or folder that you want to browse.
- 3 Tap **Up**  to go up one level in the SharePoint site.
- 4 To open the SharePoint site in your phone's web browser, tap **More**  > **Open in browser**.

The Web

Internet



Open webpages

Internet Explorer Mobile makes it easier to surf the web on the go. It includes handy features such as tabs, which let you open multiple webpages at once.





1. refresh page
2. address bar
3. add a favorite website
4. see favorites or browsing history
5. show tabs
6. more menu options

To open a webpage


- 1 On Start, tap **Internet Explorer** , then tap the address bar.
- 2 Type the web address.
As you type, Internet Explorer Mobile will suggest possible matches. If you see the site you're looking for, tap it.
3. Otherwise, tap Go .

TIPS!

- Need to search the web? Press the Search button . Or type your search term into the address bar in Internet Explorer Mobile.
- Don't see a list of suggestions when you enter an address? On Start, flick left to the Apps list, tap **Settings**  > **Internet Explorer**, and then select Let Bing suggest sites as I type.




Note: You'll need a mobile data or Wi-Fi connection to browse the web in Internet Explorer Mobile

To cancel a webpage

- 1 To stop a webpage from loading, tap Cancel  in the address bar.


To open a new tab

You can open six separate browser windows (called "tabs" in Internet Explorer Mobile) simultaneously. Tabs provide a handy way to jump around to multiple websites.

- 1 On Start, tap **Internet Explorer** , then tap **Tabs** .
- 2 Tap **New**  to open a blank tab.

TIPS! The Tabs icon  shows you the number of tabs you have open.

To switch between tabs

- 1 In Internet Explorer, tap **Tabs** .
- 2 Tap the thumbnail of the tab you want to see full screen.

Navigate webpages

Once you learn the tricks, surfing on your phone with Internet Explorer Mobile is almost as easy as surfing on your PC.

To scroll and zoom

- 1 Do one of the following:
 - Flick your finger across the screen in any direction to move the webpage. The faster you flick, the faster the page scrolls.
 - Spread your thumb and forefinger apart to zoom in on a webpage. Pinch your fingers together to zoom out.
 - Double-tap your finger on a webpage to automatically center and zoom in on that spot. Double-tap again to zoom out.



To open a link

- 1 Touch an underlined link to open it in Internet Explorer Mobile.

TIPS! If you see a phone number or street address on a website, you can often tap it to dial the number or map the address directly.



To navigate between webpages

It's easy to go back and forth between webpages or sites you've previously seen.

- 1 Do one of the following:
 - To go back, press the **Back** button  on your phone.
 - To skip ahead, tap **More** , then tap Forward.


TIPS! Use your saved browsing history to quickly return to older sites you've visited. Tap **Favorites > flick** to History, and then tap the site you want to see again.

To find text on a webpage

- 1 In **Internet Explorer Mobile**, tap **More** , then tap Find on page.
- 2 Type the word or phrase you want to find, then tap Go .

Change privacy and other browser settings

Internet Explorer Mobile makes it easy to change privacy settings on your phone and control your browsing experience.

- 1 On Start, flick left to the Apps list, and then tap **Settings** .
- 2 Flick to Applications, then tap **Internet Explorer**.

The Web

To delete cookies, history, and saved passwords

- 1 Tap **Delete history** to erase browser history, saved cookies and passwords, and temporary Internet files from your phone.

To turn cookies on or off

Cookies are small files on your phone that websites use to remember things like your password or preferences, so you don't have to retype information each time you visit. You can easily prevent cookies from being stored on your phone.

- 1 Select or clear Allow cookies on my phone to permit or block cookies from being saved on your phone.

To turn address autosuggestion on or off

Bing Search can suggest websites as you type into the address bar—potentially a big time saver.

- 1 Select or clear Let Bing suggest sites as I type.

To set your website preferences

Many websites today offer a slimmed-down version of their full desktop site that's customized for the smaller screens and slower Internet connections commonly found on mobile phones. Some people prefer these mobile sites, others don't. Internet Explorer Mobile can help show you the version you prefer.

- 1 Under Website preference, select either Mobile version or Desktop version.

Note: You'll need a mobile data or Wi-Fi connection to browse the web in Internet Explorer Mobile

Maps

Use Maps to find a place

The Maps app in Windows Phone 7 can show you where you are, where you'll find an address, and provide turn-by-turn directions straight there. It can also show you what stores or restaurants are in your vicinity and what other people are saying about them.



1. get directions
2. show your location
3. find address of place
4. more menu options

To move around the map

- 1 On Start, flick left to go to the Apps list, then tap **Maps** 

TIPS! If this is your first time accessing Maps, when you see Allow Maps to access and use your location? tap Allow.

2 Do any of the following:

- Flick your finger across the screen in any direction to move the map. The faster you flick, the faster the map scrolls.
- To zoom in, spread your thumb and forefinger apart on the map. To zoom out, pinch your fingers together.
- Double-tap the map to automatically center and zoom in on a spot. Double-tap again to get even closer.

Note: At maximum zoom, the map will automatically change to satellite view.

To find your current location

Tap **Me** .

Note: Certain features of Maps may not be available in your country or region.

You'll need a mobile data or Wi-Fi connection to use Maps.

To find an address or place

1 On Start, flick to the Apps list, then tap

Maps .



2 Tap **Search** .

3 In the search box, type any of the following:

- An address (1 Microsoft Way, Redmond, WA)
- A ZIP Code (90052)
- A city (Seattle, WA)
- A business name or type (coffee shop)
- A point of interest (Space Needle)

1 Tap **Go** .







TIPS!

- To get directions to a spot and see what's nearby, tap a pushpin. Pushpins for a store or restaurant also might include a street address, phone number, web address, and customer reviews.
- To see all the pushpins as a list, tap More  Results list. To remove pins from the map, tap More  Clear map.
- Pin a map location to Start for quicker access. Just tap a pushpin, and then tap Pin .

The Web

To get directions to an address or place

Windows Phone can guide you to your destination with written turn-by-turn directions. It also shows the total distance and estimated travel time.


- 1 On Start, flick to the Apps list, then tap **Maps** .
- 2 Tap **Directions** .
- 3 Type one of the following:
 - An address
 - A restaurant, store, or other business name
- 1 Tap **Go** .
- 2 Tap **Walking**  or **Driving** , depending on how you plan to travel.
- 3 Tap **Go** .

TIPS!

- Tap a direction to see it highlighted on the map.
- Maps assumes you always want to start from your current location. To start from someplace else, tap My Location and type another starting point.
- Instead of an address, type a business name into the destination box and Maps will automatically route you there.
- Tap Start or End to reverse the starting or ending points for your trip.

Marketplace

Marketplace lets you download useful applications and musics and games. If you install them from Marketplace, they appear in App list.

- 1 Tap  on Start to go to your App list and tap **Marketplace** application or you can also tap **Marketplace** tile on Start screen.
- 2 Marketplace has three categories - apps, games, music. Select one you need to install or download.

Connectivity

Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 10 metres without requiring a physical connection.

You do not need to line up the devices to beam information with Bluetooth. If the devices are within range of one another, you can exchange information between them even if they are located in different rooms.

NOTES:

- LG is not responsible for the loss, interception, or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.

Turn on the Bluetooth wireless feature



- 1 On Start screen, tap the arrow (→) to go to your App list.
- 2 Tap **Settings > System > Bluetooth**.
- 3 **To turn on Bluetooth, drag** the slider of status to **On**.
- 4 Starts to search the Bluetooth enabled headset.
- 5 Tap a device which you want to pair.

To connect to a Bluetooth headset

Once paired, you can connect to a Bluetooth device as needed.

- If Bluetooth is off, touch Bluetooth to turn it on. In the list of Bluetooth devices, touch the name for the paired device on the list.

Connectivity

NOTES:

- Later, when you want to turn off your Bluetooth, go to Settings, then tap Bluetooth and slide the toggle left to the Off position.
- Once the Bluetooth has been set up, the Windows Phone 7 recognizes it when it is turned on.
- Your device uses non-harmonised frequency and is intended for use in all European countries. The WLAN can be operated in the EU without restriction indoors, but cannot be operated outdoors in France.
- When the Bluetooth settings menu is displayed, your Windows Phone is visible to other devices, otherwise, your device is hidden.



Wi-Fi

Learn to use your device's wireless networking capabilities to activate and connect to any wireless local area network (WLAN) compatible with the IEEE 802.11 b/g/n standards. You can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.



Connect to a Wi-Fi network

You can use your Windows Phone to connect to an available Wi-Fi network in your location, in addition to connecting to a mobile network. Wi-Fi connections are typically faster than your mobile data connection. This can save on costs if you're not on an unlimited data plan, or if you can't connect to your mobile network for some reason. Some Wi-Fi networks are secured and may require a password before you can connect to the network.

- 1 On Start, flick left to the Apps list, and then tap **Settings**  > **Wi-Fi**.
- 2 Make sure that Wi-Fi networking is set to **On** . This ensures that your phone is actively searching for available Wi-Fi networks. If a network is found, your phone will list it and note whether it's an open or secure network.
- 3 Tap the network you want to connect to.

TIPS!

- Your phone will notify you periodically if there are available Wi-Fi networks in your area, and you can tap the notification to connect to the network, or to turn off notifications. If you don't want to be notified when a Wi-Fi network is available, return to **Settings > Wi-Fi** and clear the Notify me when new networks are found check box. When notifications are turned off, you can still check for Wi-Fi networks by returning to this screen.
- If you want to connect to a secure network, you might have to enter a user name and a password. If so, tap **Done** when you're finished.
- To disconnect from a network, tap and hold it, and then tap **Delete**.
- Your device uses non-harmonised frequency and is intended for use in all European countries. The WLAN can be operated in the EU without restriction indoors, but cannot be operated outdoors in France.

NOTES:

- To turn off Wi-Fi, go back to the Settings screen, and set **Wi-Fi to Off**.
- When you turn Wi-Fi back on, your phone will remember the network settings and automatically connect.


Play To

Play To function which is compatible with the Digital Living Network Alliance (DLNA) service. And so, learn to use Play To function that enables you to play back and control media files between DLNA-enabled devices in your home over a Wi-Fi.

Before you start!: You must first activate the Wi-Fi feature and add a Wi-Fi network connection profile.

Customise Play To settings for Streaming media files

To allow other DLNA-enabled devices to receive media files from your device, you must activate Play To(media sharing).

- 1 On Start screen, tap the arrow  to go to your App list and select Play To.
- 2 Tap Device icon on the notification bar.
- 3 Adjust the following settings to customise the Play To feature:
 - **Settings > System > Wi-Fi to On**.
 - You need to be connected to the Wi-Fi network before you choose the target device for Play To.


NOTES:

- Some files may not play on the DLNA-enabled devices.
- Playback may not be instantaneous, but instead buffered, depending on the network connection and the connected server.
- You will need a DLNA-certified device that supports DMR (Digital Media Render) service

Connectivity

for use with Play To. Go to <http://www.dlna.org/products/> to check if your device is compatible.





Play your files on another DLNA enabled device

- 1 On Start screen, tap the arrow  to go to your App list and select **Play To**.
- 2 Tap **Device** icon on the notification bar and choose target.
Your device automatically searches for DLNA-enabled devices.
- 3 Select a media category > the media file you wish to play.
- 4 Playback begins at the selected player.
Control playback using icons of your device.

NOTE: Playback may be buffered, depending on the network connection and the connected server.



Utilities

Alarms

- 1 Tap  on Start to go to your App list and tap **Alarms**  application.
- 2 If you want to add a new alarm, tap  on the bottom option menu bar.
- 3 Touch Time to set the time you want the alarm to sound.
- 4 Set the repeat.
The icons indicate the weekday you select.
- 5 Choose the sound you would like and enter a name for the alarm. When you are finished, touch  at the bottom of the page to save your alarm.

Note: To delete one alarm, tap on the alarm item to open it, and then tap **Delete**.

Calculator

- 1 Tap  on Start to go to your App list and tap **Calculator**  application.
- 2 Touch the number buttons to enter numbers.
- 3 For simple calculations, touch the function you want (+, -, x, or ÷), followed by =.
- 4 For more complex calculations, change the display mode to landscape, then choose sin, cos, tan, log, and so on.



Search

Search for stuff

The Search button is your one-push avenue to fast answers, both on and off your phone. In addition to web searches, you

can also press Search to find email, calls, contacts, or new apps to buy. It all depends on the app you're using when you press it.

To find something on the web


- 1 Press the Search button  .
(If you press Search within call history, email, Marketplace, or People, you'll need to press it again to search the web. Otherwise you'll be searching just those apps.)
- 2 Tap the Search box, then type a word or phrase.
- 3 Tap **Go**  .

TIPS! You can narrow or broaden your search results by flicking to Web, Local, or News.

Note

- Certain features of Bing, such as local search, may not be available in your country or region.
- You'll need a cellular data or Wi-Fi connection to search the web, Maps, or Marketplace.

Settings

In this menu, you can personalise the setting of your phone. Touch  on start to go to app list and tap settings.

System Settings

ringtones & sounds

You can adjust the sounds for Ringtone, New text message, New voicemail, New email and other options.

Set to play a sound for Appointment reminders, Key press, Lock and unlock, All other notifications.

theme

Change your phone's background and accent color to match your mood today, this week, or all month.

airplane mode

Toggle your phone's mobile, Wi-Fi, and Bluetooth radios simultaneously. You'll still be able to toggle Wi-Fi and Bluetooth separately.

Wi-Fi

Turn on Wi-Fi to connect to available Wi-Fi networks.

Wi-Fi settings – Set network notification, or add a Wi-Fi network

Bluetooth

Search and connect to Bluetooth devices.

email & accounts

Set up email, contacts, Facebook and others.

lock & wallpaper

Set to change wallpaper and screen time-out.

Toggle to set password and create a 4-digit password.

location

Applications for which you've previously enabled location services can now access your current location.

mobile network

Set Data connection and Data roaming. Toggle to set 3G connection and select Network.

date & time

Set date, time, and time zone

brightness

Adjust the brightness of the screen.

keyboard

Set Keyboard languages. You can check to Suggest text and highlight misspelt words, Correct misspelt words, Insert a space after selecting a suggestion, Insert a full-stop after double-clicking the SPACEBAR, Capitalise the first letter of a sentence.

region & language

Set Display language, Region format, Short date, Long date, First day of week, System locale and Browser & search language.

ease of access

Set TTY/TDD mode

speech

Set to Play audio confirmations and Use Speech when the phone is locked.

find my phone

Map, ring, lock or erase your phone at windowsphone.live.com

When you've lost your phone, it will help you find your phone. Go to windowsphone.live.com and sign in with your Windowslive ID and password.

phone update

Notify you when new updates are found. Use your mobile data connection to check for updates.

about

View legal information, and check phone status and software version.

feedback

Send feedback to help improve Windows Phone

Applications Settings

games

Connect to Xbox LIVE On/Off.

Internet Explorer

Check whether you allow cookies on your phone or not. Also you can set if you let Bing suggest sites as you type.

Choose website preference.

Mobile version or Desktop version

delete history

Delete all temporary files, history, cookies and saved passwords from Internet Explorer.

maps

Toggle Use my location On/Off.

It uses your location to provide you with better local search results.

delete history

Delete previous map searches, pins and image data from your phone.

messaging

This is used to send and receive messages.

music & videos

Connect with Zune On/Off.

Turn on to automatically download information that enhances your Zune experience.

Settings

Office

username

Enter your user information to identify yourself in comments and to help with collaboration and document tracking.

SharePoint

- data store
You can create space on your phone by clearing the SharePoint cache. This will delete all temporary SharePoint files and history.
- conflicts
SharePoint lets you choose how to manage conflicts between files on your phone and the server. You can choose the way you want to resolve conflicts.
 - Notify me and I'll resolve the conflict manually.
 - Automatically replace item on the phone.
- startup option
Check to always open SharePoint links.
- reset
Restore default settings.

OneNote

Toggle Automatic synchronization On/Off.
Turn on to automatically synchronise notes when you open a page, save a page or open a section.

people

Import SIM contacts will be synced with your online Windows Live contact list.

- Sort list by First name / Last name.
- Display names by First Last / Last, First.

phone

Set Voicemail number.

Show my caller ID to everyone / no one / my contacts

Call forwarding On/Off

International assist On/Off

SIM security On/Off

pictures + camera

Set options below.

Allow the camera button to wake up the phone On/Off.

Include location (GPS) information in pictures you take On/Off.

Auto upload to SkyDrive On/Off.

Keep location information on uploaded pictures On/Off.

radio

Set regional options.

North America / World / Japan

search

Toggle Use my location On/Off.

It uses your location to provide you with better local search results.

Check to get suggestions from Bing as you type.

delete history

Delete previously entered search terms from your phone.

Software update

Phone Software update

Windows Phone Update enables you to update the firmware of your phone to the latest version. Your phone are alerted to Windows Phone Updates automatically by the Windows Phone Update service, and the updates are installed on the phone by using the Zune software running on the user's personal computer. Please go to 'PHONE' menu of settings from the Zune software and click 'UPDATE' to check for updates available.

Accessories

There are a variety of accessories available for your mobile phone, which may be sold separately. Select these options according to your personal communication needs. Consult your local dealer for availability. (Items described below may be optional.)

Charger

Output /Sortie:
4.8V/ 1.0A



Data cable

Connect your
LG-C900B and PC.



Battery



User Guide

Learn more about
your LG-C900B.



Stereo headset



Microsoft SHG (start here guide)

Help you get
started with your
Windows Phone.



NOTE:

- Always use genuine LG accessories.
- Failure to do this may invalidate your warranty.
- Accessories may vary in different regions.

Ambient Temperatures

Max: +55°C (discharging),
+45°C (charging)

Min: -10°C

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING

To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby in adequately shielded electronic equipment. You should consult with

manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone.

Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 74 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- Never place your phone in a microwave oven as it will cause the battery to explode.
- Do not dispose of your battery by fire or with hazardous or flammable materials.
- Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- Store the battery in a place out of reach of children.
- Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- Do not use a hand-held phone while driving.
- Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- Never store your phone in temperatures less than- 4°F or greater than 122°F.
- Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- Do not use your phone in high explosive areas as the phone may generate sparks.
- Do not damage the power cord by bending, twisting, pulling, or heating.
- Do not use the plug if it is loose as it may cause a fire or electric shock.
- Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- Do not disassemble the phone.
- Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- Do not hold or let the antenna come in contact with your body during a call.
- An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.
- Use accessories, such as earphones and headsets, with caution. Ensure that cables are tucked away safely and do not touch the antenna unnecessarily.

For Your Safety

Memory card information and care

- Always insert/ remove the memory card while the handset power is off. If you remove it while the power is on, it may be damaged.
- If a damage cannot be fixed, format the memory card.
- The memory card cannot be used for recording copyright protected data.
- Do not write forcefully on the memo area.
- Carry and store the memory card in its case.
- Do not allow the memory card to get wet.
- Do not leave the memory card in extremely hot location.
- Do not disassemble or modify the memory card.

FCC RF Exposure Information



WARNING

Read this information before operating the phone.

In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those

guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 2cm (0.79 inches) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 2cm (0.79 inches) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used.

Body-worn accessories that cannot maintain 2cm (0.79 inches) separation distance between the user's body and the

back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 20cm (8 inches) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules and ICES-003 Class B digital apparatus requirements for Industry Canada. Operation is subject to the following two conditions:

(1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

Cautions for Battery

- Do not disassemble.
- Do not short-circuit.
- Do not expose to high temperature: 60°C (140°F).
- Do not incinerate.

Battery Disposal

- Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- Do not dispose in fire or with hazardous or flammable materials.

Adapter (Charger) Cautions

- Using the wrong battery charger could damage your phone and void your warranty.
- The adapter or battery charger is intended for indoor use only.

Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Avoid damage to your hearing

- Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when attempting to cross the street.

Safety Guidelines

TIA Safety Information

Provided herein is the complete TIA Safety Information for Wireless Handheld phones. Inclusion of the text covering Pacemakers, Hearing Aids, and Other Medical Devices is required in the owner's manual for CTIA Certification. Use of the remaining TIA language is encouraged when appropriate.

Exposure to Radio Frequency Signal

Your wireless handheld portable telephone is a lowpower radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones.

Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *

NCRP Report 86 (1986)

ICNIRP (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

* American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection

The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

For your phone to operate most efficiently:

- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Driving

Check the laws and regulations on the use of wireless phones in the areas where you drive. Always obey them. Also, if using your phone while driving, please:

- Give full attention to driving - driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6') inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker.

These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers:

- Should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket.
- Should use the ear opposite the pacemaker to minimize the potential for interference.

- If you have any reason to suspect that interference is taking place, turn your phone OFF immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

Safety Guidelines

You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Turn your phone OFF before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a 'blasting areas or in areas posted: 'Turn off two-way radio'. Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, marked clearly.

Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied

petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Safety Information

Please read and observe the following information for safe and proper use of your phone and to prevent damage. Also, keep the user guide in an accessible place at all the times after reading it.

Charger and Adapter Safety

- The charger and adapter are intended for indoor use only.

Battery Information and Care

- Please dispose of your battery properly or take it to your local wireless carrier for recycling.
- The battery does not need to be fully discharged before recharging.

- Use only LG-approved chargers specific to your phone model since they are designed to maximize battery life.
- Do not disassemble or impact the battery as it may cause electric shock, short-circuit, and fire. Store the battery in a place out of reach of children.
- Keep the battery's metal contacts clean.
- Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
- Recharge the battery after long periods of non-use to maximize battery life.
- Battery life will vary due to usage patterns and environmental conditions.
- Use of extended backlighting, Media Net Browsing, and data connectivity kits affect battery life and talk/standby times.
- The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal state. In this case, remove the battery from the phone, reinstall it, and turn the phone on.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Explosion, Shock, and Fire Hazards

- Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it is dirty.
- When using the power plug, ensure that it is firmly connected. If it is not, it may cause excessive heat or fire.
- If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone. Always cover the receptacle when not in use.
- Do not short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and – terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.

General Notice

- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book or subway ticket near your phone. The magnetism of the phone

Safety Guidelines

- may damage the data stored in the magnetic strip.
- Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Centre to replace the damaged antenna.
- Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Centre.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.
- When you use the phone in public places, set the ring tone to vibration so as not to disturb others.

- Do not turn your phone on or off when putting it in your ear.

FDA Consumer Update

The U.S. Food and Drug Administration Centre for Devices and Radiological Health Consumer Update on Mobile Phones.

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the standby mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is the FDA's role concerning the safety of wireless phones?

Under the law, the FDA does not review the safety of radiation emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, the FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace, or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing of wireless phones with the best possible information on possible effects of wireless phone use on human health.

The FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Occupational Safety and Health Administration (Administración de la seguridad y salud laborales)
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

The FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. The FCC relies on the FDA and other health agencies for safety questions about wireless phones.

The FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they

Safety Guidelines

can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term 'wireless phone' refers here to handheld wireless phones with built-in antennas, often called 'cell', 'mobile', or 'PCS' phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by FCC safety guidelines that were developed with the advice of the FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called 'cordless phones,' which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal

experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer causing chemicals so as to be predisposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health. Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures.

However, none of the studies can answer questions about longterm exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but 10 or more years follow-up may be needed to provide answers about some health effects, such as cancer.

This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is the FDA doing to find out more about the possible health effects of wireless phone RF?

The FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF). The FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The project has also helped develop a series of public information documents on EMF issues. The FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. The FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIAfunded research is conducted through contracts with independent investigators. The initial research will include both laboratory studies and studies of wireless phone users.

Safety Guidelines

The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much radiofrequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit radiofrequency energy (RF) exposures.

The FCC established these guidelines in consultation with the FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless telephones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (<http://www.fcc.gov/oet/rfsafety>) gives directions for locating the FCC identification number on your phone so

you can find your phone's RF exposure level in the online listing.

8. What has the FDA done to measure the radiofrequency energy coming from wireless phones?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the radiofrequency energy (RF) exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists and engineers. The standard, 'Recommended Practice for Determining the Spatial-Peak Specific Absorption Rate (SAR) in the Human Body Due to Wireless Communications Devices: Experimental Techniques,' sets forth the first consistent test methodology for measuring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissuesimulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure. If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna. Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones,

including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure. Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, the FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless

Safety Guidelines

telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by the FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. The FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a 'compatible' phone and a 'compatible' hearing aid at the same time. This standard was approved by the IEEE in 2000. The FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, the FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information?

For additional information, please refer to the following resources:
FDA web page on wireless phones (<http://www.fda.gov/cdrh/phones/index.html>)

Federal Communications Commission (FCC) RF Safety Program (<http://www.fcc.gov/oet/rfsafety>)

International Commission on Non-Ionizing Radiation Protection (<http://www.icnirp.de>)

World Health Organization (WHO) International EMF Project (<http://www.who.int/emf>)

National Radiological Protection Board (UK) (<http://www.nrpb.org.uk/>)

10 Driver Safety Tips

Your wireless phone gives you the powerful ability to communicate by voice almost anywhere, anytime. An important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When operating a car, driving is your first responsibility.

When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

- 1.** Get to know your wireless phone and its features such as speed dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most phones offer, including automatic redial and memory. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.
- 2.** When available, use a handsfree device. A number of handsfree wireless phone accessories are readily available today. Whether you choose an installed mounted device for your wireless phone or a speaker phone accessory, take advantage of these devices if available to you.
- 3.** Position your wireless phone within easy reach. Make sure you place your wireless phone within easy reach and where you can reach it without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
- 4.** Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.
- 5.** Do not take notes or look up phone numbers while driving. If you are reading an address book or business card, or writing a “to-do” list while driving a car, you are not watching where you are going. It is common sense. Don’t get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.
- 6.** Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip or attempt to coincide your calls with times you may be stopped at a stop sign, red light or otherwise stationary. But if you need to dial while driving, follow this simple tip — dial only a few numbers, check the road and your mirrors, then continue.
- 7.** Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix; they are distracting and even dangerous when you are behind the wheel of a car. Make people you are talking with aware you are driving and if necessary, suspend conversations which have the potential to divert your attention from the road.
- 8.** Use your wireless phone to call for help. Your wireless phone is one of the greatest tools you can own to protect yourself and your family in dangerous situations — with your phone at your side, help is only three

Safety Guidelines

numbers away. Dial 911 or other local emergency number in the case of fire, traffic accident, road hazard or medical emergency. Remember, it is a free call on your wireless phone!

9. Use your wireless phone to help others in emergencies. Your wireless phone provides you a perfect opportunity to be a “Good Samaritan” in your community. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.
10. Call roadside assistance or a special wireless nonemergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call for emergency services. But you can still use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.

For more information, please call to 888-901-SAFE, or visit our website www.wow-com.com

Consumer Information on SAR (Specific Absorption Rate)

This Model Phone Meets the Government’s Requirements for Exposure to Radio Waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *

Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands.

Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

The highest SAR value for this model phone when tested for use at the ear is 0,67 W/kg and when worn on the body, as described in this user's manual, is 0,54 W/kg. (Body-worn measurements differ among phones models, depending upon available accessories and FCC requirements.) While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after

searching on FCC ID BEJC900K.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.ctia.org/>.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

* Product meets current FCC & IC Radio Frequency Exposure Guidelines.
FCC ID: BEJC900K
IC ID: 2703C-C900B

FAQ

Please check to see if any problems you have encountered with the phone are described in this section before taking the phone in for a service or calling a service engineer.

Category	Sub-Category	Question	Answer
Bluetooth	Bluetooth Headset	Is it possible to hear sound from the phone, when BT headset is paired and connected to Windows Phone 7?	In the case where headphone is physically connected (via 3.5" jack) to Windows Phone 7, while BT headset is also connected wirelessly, user will hear sound from the heaphone ONLY. * Please check, as no sound will result via BT headset in such scenario *
Bluetooth	Bluetooth Headset	You cannot listen to music on a remote Bluetooth headset	* Check you do not have headphones connected to the phone. • Ensure that your device is connected to the Stereo headset. • Ensure that the music format you are trying to listen to is supported by the headset. • Ensure that the distance between the headset and device is not more than 10 metres and that they are not separated by walls or other obstacles.
Bluetooth	Bluetooth Headset	You cannot listen to video sound on a remote Bluetooth headset	It's not supported. If you want to listen to video sound, please use the ear-jack instead of Bluetooth headset.
Bluetooth	Bluetooth supported Profile	Which profiles are supported for Windows Phone 7?	HFP (HandsFreeProfile) HSP (HeadSet Profile) A2DP(Advanced Audio Distribution Profile) AVRCP(A/V Remote Control Profile) - Music : only support Play/Pause/Previous Song/Next Song PBAP(Phone Book Access Profile)
Bluetooth	Bluetooth Connection	What are the functions available via Bluetooth?	Connecting to Stereo/Mono Headset, Car Kit is possible.

Category	Sub-Category	Question	Answer
Bluetooth	Bluetooth Connection	Is it possible to use internet when synchronising between phone and pc? (In such case, where pc is connected with wired LAN).	It's not supported.
Bluetooth	Contact transmission	Is there any way to transfer the contacts data to other phone thru bluetooth? Ex) Contacts of other phone move to phone via BT.	It's not supported.
Bluetooth	Print	Can you print MS office document (MS word, excel, PDF, etc.) using BT or wireless?	It's not supported.
Data	Backup	How do you import contacts from your old phone to your Window Phone 7?	<ul style="list-style-type: none"> Put your old SIM card into your new phone, then go to Settings. Flick to applications, tap people > import SIM contacts. You cannot do this through Zune.
Data	Synchronization	What are some limitations, when data synchronising between windows phone 7 and pc?	In Window Phone 7, "Zune" application is used instead of "Activesync". The limitation of Zune is, while synchronizing, (music, video and picture) files can not be played on the phone.
Data	Synchronization	How do you synchronise between phone and pc under Windows Vista & Win7?	By using microsoft application "Zune" which can be downloaded from MS website.
Data	Web-Upgrade	Is it possible to backup the user data automatically when upgrading thru Web.	Zune supports whole flash backup, but does not support backup of user data seperately.
Misc.	Call Time	Is the Calling time calculated differently according to the model(Ex. 2G/3G, CDMA ...)	CDMA Model : Calling time is calculated from when you press "call" after dialling the number. 2G/3G Model : Calling time is calculated from when the call is connected.
Misc.	E-Mail	Where do you get POP3 & SMTP Server settings?	Please consult email system administrator for assistance.

FAQ

Category	Sub-Category	Question	Answer
Misc.	Active X	Is the Active X supported like PC?	No, it's not supported.
Phone Function	Battery	How do you check if battery is fully charged?	Battery charge status is displayed on top of the screen.
Phone Function	W&P option	Is it possible to use W(Wait) & P(Pause) option, when saving phone number to contacts?	Yes, it's possible. But it's supported using the hardware keyboard only. it's not supported for the on-screen keyboard.
Phone Function	Office Mobile	Is it possible to edit files in office applications of mobile?	It's only possible to read. • Please note that Microsoft Office Mobile doesn't support all the features that are found in Microsoft Office 2010. If a document has content that's not supported in Office Mobile, you can still open the document on your phone, but the unsupported content won't be displayed.
Phone Function	Ring Tone Setting	How do I set the Ring Tone?	Go to Application list and tap Settings > ringtone & sounds to set up the Ring Tone. there are different kinds of alerts and different ringtones you can assign to different people. On start, tap People > the contact you want to change > Edit > Rigtone .
Phone Function	Ring Tone Setting	How can I use my favourite music as a ringtone?	Marketplace enables users to easily find & acquire your favourite ringtone Go to Application list and tap Marketplace > Music . And browse and choose your favourite ringtone. Please note that Marketplace may not be available in your country or region.

Category	Sub-Category	Question	Answer
Phone Function	Supported Language	Is it possible to change the language?	Your Windows Phone 7 supports 6 different languages (Deutsch, English (United Kingdom/ United States), Español, Français, Italiano). If you want to change the settings, go to tap Settings > region & language > Display language .
Phone Function	Sound Settings	How to setup the system sound and Ring sound?	You can adjust the music, ringtone and system sound with volume keys. • Go to " Settings > ringtone & sounds "
Phone Function	Time Setting	How do you set the time on the phone?	Applications list > Settings > date & time > Set automatically slider to Off > Set the Time
Phone Function	Youtube	Is it possible to view video clips from Youtube?	This is possible via use of Marketplace YouTube player. Please note that Marketplace YouTube player may not be available in your country or region.
Phone Function	Battery Life Time	What is the talk time of this phone?	Calling : 360 min. (based on 3G) Standby time : 350 hours
Phone Function	camera	Is there any option to save or erase a picture, right after it's taken?	Picture is saved automatically. Navigate to Picture Viewer by flicking to the right. Touch and hold the picture taken. View available options. (eg. Adding to favourites, deleting etc).
Phone Function	E-mail	Is it possible to set e-mail filtering?	E-Mail filtering is possible via use of "Search" button.

FAQ

Category	Sub-Category	Question	Answer
Phone Function	E-mail	Is it possible to set the alert sound when receiving e-mail?	[Steps] Settings > ringtones & sounds > New email > Choose an item
Phone Function	browser settings	How can I change privacy and other browser settings?	Go to Settings > applications > Internet Explorer to delete cookies. Also, you can turn off sharing your location using Settings > system > location .
Phone Function	Proximity Sensor	How do you keep the LCD screen on, during phone conversation?	Proximity sensor on the phone is designed to switch the LCD off by default whilst on a call.
Phone Function	SIM Lock	Is it possible to use SIM Card that's provided by different operator?	Please contact the store that sold you the phone to check if a SIM lock is active or not. If there is no SIM Lock, certain features or services might not be available due to phone or network settings.
Phone Function	SIM Lock	My Windows Phone has a SIM lock, can LG help me in this case?	SIM lock depends on the network operator that sold you the Windows Phone. Please contact the network operator or the store that sold you the Windows Phone.
Phone Function		Is Adobe Flash supported (similar to PC browser)?	It's not supported.
Phone Function		Is Streaming service supported.	Some streaming protocols are not supported (e.g. RTSP). HTTP-Progressive and IIS SmoothStreaming is supported depending on the website you are visiting and the application you are using.
Phone Spec	Band	Is GSM technology Quadra band, tri band or dual band? (For example: 1900Mhz, 900, 1800, 850)	Quad band is supported.
Phone Spec	Phone Spec	Is it possible to use external GPS device?	No. There is a built-in GPS unit in your Windows Phone 7 device.

Category	Sub-Category	Question	Answer
Recovery Solution	Password missing	What do you do, when you've forgotten your password? How do you obtain your password, if forgotten?	Contact your service provider.
Recovery Solution	Factory Rest Web update	I want to reset my phone to improve performance, how do I do this? I want to update the software running on my phone to improve performance, how do I do this?	<p>1. Factory Reset. Go to tap Applications list > Settings > about > reset your phone.</p> <p>Resetting your phone will erase all your personal content, including applications that you purchased and downloaded, and will restore the factory settings.</p> <p>2. Try to update latest SW version via Web. Your phone are alerted to Windows Phone Updates automatically by the Windows Phone Update service, and the updates are installed on the phone by using the Zune software running on your personal computer, when you connect your phone with it.</p> <p>If you didn't install the Zune software yet, go to www.microsoft.com/windowsphone/en-ca/howto/wp7/start/install-the-zunesoftware.aspx to install.</p> <p>Warning! By performing "Factory Reset", all user data will be ERASED. Customer MUST backup PRIOR to running factory reset & Web update.</p>
Wi-Fi	Wi-Fi Simple Inquiry	What can I do with Wi-Fi (wireless networking)?	You can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.

LIMITED WARRANTY STATEMENT

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

1. The limited warranty for the product extends for ONE (1) year beginning on the date of purchase of the product by the original end user.
2. The limited warranty extends only to the original end user of the product and is not assignable or transferable to any subsequent purchaser/end user.
3. This warranty is good only to the original end user of the product during the warranty period as long as it is in Canada.
4. Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
5. During the applicable warranty period, LG will repair or replace at LG's sole option, without charge to the original end user, any defective component part of the phone or accessory.
6. LG may use rebuilt, reconditioned or new parts or components when repairing any product or replace a product with a rebuilt, reconditioned or new product.

2. WHAT THIS WARRANTY DOES NOT COVER:

1. Defects or damages resulting from use of the product in other than its normal and customary manner.
2. Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation or other acts which are not the fault of LG, including damage caused by spills of food or liquids.
3. Breakage or damage to antennas unless caused directly by defects in material or workmanship.
4. The fact that the Customer Service Department at LG was not notified by the original end user of the alleged defect or malfunction of the product, during the warranty period.
5. Products which have had their serial numbers removed or made illegible.
6. Damage resulting from use of non-LG approved accessories.
7. All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.

8. Products serviced by non-authorized persons or companies.

Notes:

1. This limited warranty supersedes all other warranties, expressed or implied either in fact or by operations of law, statutory or otherwise, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose.
2. Shipping damage is the sole responsibility of the shipping company.

3. EXCLUSION OF LIABILITY:

No other express warranty is applicable to this product.

THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG ELECTRONICS CANADA, INC. SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT.

4. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call the following telephone number from anywhere in Canada:

LG Electronics Canada, Inc.

Tel. 1-888-LG-Canada (1-888-542-2623)

http://www.lg.com/ca_en (see links to "Support > Mobile Phone Support")



LG Electronics Canada Inc.

Mississauga, Ontario