

USING THE PROGRAM GUIDE

The on-screen **Program Guide** provides a complete listing of the available channels and programs. You can use the **Program Guide** to change channels, to see what programs are scheduled, to set up timers, and to buy pay per view programs.

Tue 08/06	10:30pm	11:00pm	11:30pm
202 ATV	News	The Daily Show	eTalk Daily
201 NTV	← The Jury	CTV News	News →
200 CBC-A	Berkeley Square		Off Air →
199 XPRS	← ATV News	NTV News	
198 XPRS2	TVI	Utilisation de votre récepteur	Quoi de neuf?

The **Program Guide** shows which **Favourites List** is active. If the **All Chan** list is active, the Program Guide shows all of the channels available from Bell ExpressVu. If the **All Sub** list is active, the **Program Guide** displays only the channels in your subscription. When another list is active, the **Program Guide** displays only the channels in that list.

For more information, see *Using Favourites Lists* on page 3-16. The **Program Guide** shows programs that are on now and that are scheduled several days in advance. The guide does not show programs that have ended.

CHANGING THE CHANNEL IN THE PROGRAM GUIDE

Remote
Buttons

Menu Options


1. Press Guide to open the **Program Guide**.

GUIDE



2. Choose a channel using either of the following:

- Use the number pad buttons to enter the channel number. The **Program Guide** displays a block of channels including the one that you just entered.
- Use the Arrow buttons to move the highlight to the channel.



3. Press the Select button to change to the new channel.

4. Press the Cancel button to close the **Program Guide** without changing the channel.



CANCEL

SCROLLING THROUGH THE PROGRAM GUIDE

There are two ways to scroll through the **Program Guide**:

- Scroll by channel - Press the Page Up or Page Down button to scan, page by page, through the listing of channels.
- Scroll by time - Enter the number of hours that you want to skip, using the number pad buttons. Then, press the Left or Right arrow button.
- Scroll by day - Press Skip FWD to scroll ahead in the **Program Guide** 24 hours each time you press the button. After you skip ahead at least one day in the **Program Guide**, press Skip Back to scroll back 24 hours each time you press the button (until you are on the current date).

